

PROVu PD6400 High Voltage and Current Meter Instruction Manual



PROVu®
SERIES

MeterView Pro

USB Install 



High Voltage & Current

- One High Voltage and One High Current Input
- 0-300 VAC or VDC Voltage Input
- 0-5 AAC or ADC Current Input
- Displays Voltage and Current Simultaneously
- Multiplication for Apparent Power Calculation
- Dual-Line Display
- NEMA 4X and IP65 Rated Front Panel
- UL Listed & CE Marked
- Display Features 0.6" & 0.46" Digits
- Six Full Digits on Each Line
- Optional Superluminous Sunlight Readable Display
- Free USB Programming Software & Cable
- 2 or 4 Relays + Isolated 4-20 mA Output Options
- USB, RS-232, & RS-485 Serial Communication Options
- External 4-Relay & Digital I/O Expansion Modules
- Input Power Options Include 85-265 VAC or 12-24 VDC
- Isolated 24 VDC @ 200 mA Transmitter Power Supply
- Modbus® RTU Communication Protocol Standard

**PRECISION
DIGITAL**

Disclaimer

The information contained in this document is subject to change without notice. Precision Digital makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose.

 CAUTION <i>Read complete instructions prior to installation and operation of the meter.</i>	 WARNING! <i>Risk of electric shock or personal injury.</i>
 WARNING! <i>This product is not recommended for life support applications or applications where malfunctioning could result in personal injury or property loss. Anyone using this product for such applications does so at his/her own risk. Precision Digital Corporation shall not be held liable for damages resulting from such improper use.</i>	

Limited Warranty

Precision Digital Corporation warrants this product against defects in material or workmanship for the specified period under “Specifications” from the date of shipment from the factory. Precision Digital’s liability under this limited warranty shall not exceed the purchase value, repair, or replacement of the defective unit.

Registered Trademarks

PROVu® and MeterView® Pro are registered trademarks of Precision Digital Corporation. Modbus® is a Registered Trademark of Schneider Automation Inc. All other trademarks mentioned in this document are the property of their respective owners.

© 2017 Precision Digital Corporation. All rights reserved.

Table of Contents

Table of Contents	3	Setting the Relay Operation (rELAY)	26
Table of Figures	4	Setting the Relay Assignment (R55, In)	26
Introduction	4	Setting the Relay Action	27
Ordering Information	5	Programming Set and Reset Points	27
Specifications	6	Setting Fail-Safe Operation	27
General	6	Programming Time Delay	27
Voltage and Current Inputs	6	Relay Action for Loss of Input (Loop Break)	27
Relays	7	Relay and Alarm Operation Diagrams	28
Isolated 4-20 mA Transmitter Output	7	High Alarm Operation (Set > Reset)	28
Modbus® RTU Serial Communications	7	Low Alarm Operation (Set < Reset)	28
MeterView Pro	8	High Alarm with Fail-Safe Operation (Set > Reset)	28
Compliance Information	8	Low Alarm with Fail-Safe Operation (Set < Reset)	28
Safety	8	Relay Sampling Operation	29
Electromagnetic Compatibility	8	Signal Loss or Loop Break Relay Operation	29
Safety Information	9	Time Delay Operation	30
Installation	9	Relay Operation Details	31
Unpacking	9	Overview	31
Panel Mounting Instructions	9	Relays Auto Initialization	31
Mounting Dimensions	10	Fail-Safe Operation	31
Connections	10	Front Panel LEDs	31
Connectors Labeling	10	Latching and Non-Latching Relay Operation	32
Power Connections	11	Non-Latching Relay (Auto)	32
Signal Connections	11	Non-Latching Relay (R-nn Rn)	32
Voltage Input	11	Latching Relay (LATCH)	32
Current Input	11	Latching Relay (Lt-LLr)	32
Current and Voltage Input	12	Acknowledging Relays	33
Modbus RTU Serial Communications	12	Pump Alternation Control Applications (RLtErn)	33
Relay Connections	13	Setting Up the Interlock Relay (Force On) Feature	33
Switching Inductive Loads	13	Interlock Relay Operation Example	34
F4 Digital Input Connections	14	Scaling the 4-20 mA Analog Output (Rout)	34
4-20 mA Output Connections	14	Reset Menu (rESEt)	34
Analog Output Transmitter Power Supply	14	Control Menu (Contrl)	34
External Relay, Analog Output, & Digital I/O	15	Setting Up the Password (PR55)	35
Connections	15	Protecting or Locking the Meter	35
Interlock Relay Feature	15	Making Changes to a Password Protected Meter	35
Setup and Programming	16	Disabling Password Protection	35
Front Panel Buttons and Status LED Indicators	16	Advanced Features Menu	36
MeterView® Pro Software	17	Advanced Features Menu & Display Messages	36
MeterView Pro Installation	17	Noise Filter (F, LtEr)	38
Display Functions & Messages	18	Noise Filter Bypass (bYP555)	38
Main Menu	20	Rounding Feature (round)	38
Setting Numeric Values	20	Modbus RTU Serial Communications (SEr, RL)	39
Setting Up the Meter (SEtUP)	21	Select Menu (SELEct)	39
Setting the Decimal Point (dEc Pt)	21	Multi-Point Linearization (L, nERr)	40
Setting the Input Calibration (InCAL)	22	Math Function (nn Rth)	40
Multi-Point Linearization (L, nERr)	22	Math Constants (ConSt)	40
Scaling the Meter without a Signal Source	22	Low-Flow Cutoff (CutOFF)	40
Scaling the Meter for Channel A (SCAL -A)	22	Analog Output Programming (RoutPr)	40
Scaling the Meter for Channel V (SCAL -V)	22	Programmable Function Keys User Menu (uSEr)	41
Error Message (Error)	23	Internal Calibration (InCAL)	43
Calibrating the Meter with External Source	23	Meter Operation	45
Calibrating the Meter for Channel A (CAL -A)	23	Front Panel Buttons Operation	45
Calibrating the Meter for Channel V (CAL -V)	23	Function Keys Operation	45
Setting the Display Parameter & Intensity (dSPARy)	24	F4 Operation	45
Setting the Input Units or Custom Tags (unIt5)	25	Maximum/Minimum Readings	45
		Troubleshooting	46
		Diagnostics Menu (d, RL)	46

Determining Software Version	46	Troubleshooting Tips	49
Reset Meter to Factory Defaults	46	EU Declaration of Conformity	51
Factory Defaults & User Settings	47		

Table of Figures

Figure 1. 1/8 DIN Panel Cutout Dimensions	9	Figure 12. AC Current and Voltage Connections	12
Figure 2. Panel Mounting Details	9	Figure 13. AC Current Transformer and Voltage Connections	12
Figure 3. Meter Dimensions - Side View	10	Figure 14. DC Current and Voltage Connections	12
Figure 4. Meter Dimensions - Top View	10	Figure 15. Relay Connections	13
Figure 5. Connector Labeling for Fully Loaded PD6400	10	Figure 16. AC and DC Loads Protection	13
Figure 6. Power Connections	11	Figure 17. Low Voltage DC Loads Protection	13
Figure 7. AC Voltage Input Connection	11	Figure 18. F4 Digital Input Connections	14
Figure 8. DC Voltage Input Connections	11	Figure 19. 4-20 mA Output Connections	14
Figure 9. AC Current Connections	11	Figure 20. Interlock Connections	15
Figure 10. AC Current Transformer Connections	11	Figure 21. Acknowledge Relays w/Function Key or Digital Input	33
Figure 11. DC Current Connections	12		

Introduction

The PROVu® PD6400 is a multipurpose, easy-to-use high voltage and current input meter ideal for measuring direct voltage and current or the output from voltage shunts and current transformers. It has one 0-300 VAC or VDC voltage input and one 0-5 AAC or ADC current input. The meter may be used with a single voltage or current input, or to measure both simultaneously. A math channel P calculates apparent power as the product of the voltage and current inputs.

The PD6400 can display voltage, current, and apparent power. The dual line display can display any two parameters simultaneously, or can alternate between any parameters as well as their programmable units and tags. Its superluminous LED digits make it easily readable in smoke, dust, fog, and, with the optional SunBright® display, even direct sunlight.

A fully loaded PD6400 meter has the following: four SPDT relays, 4-20 mA output, and a 24 VDC power supply. The PD6400 capabilities may be enhanced by adding the following external expansion modules: four SPST relays; creating an eight-relay meter, two digital I/O modules with four inputs and four outputs each, serial communication adapters for use with MeterView Pro or Modbus RTU, and a dual 4-20 mA expansion module; for a total of three 4-20 mA analog outputs.

Ordering Information

Standard Models

85-265 VAC Model	12-24 VDC Model	Options Installed
PD6400-6R0	PD6400-7R0	No options
PD6400-6R2	PD6400-7R2	2 relays (PD1102*)
PD6400-6R3	PD6400-7R3	4-20 mA output (PD1103*)
PD6400-6R4	PD6400-7R4	4 relays (PD1104*)
PD6400-6R5	PD6400-7R5	2 relays & 4-20 mA output (PD1105*)
PD6400-6R7	PD6400-7R7	4 relays & 4-20 mA output (PD1107*)
*Model number for replacement option card.		

SunBright Display Models

85-265 VAC Model	12-24 VDC Model	Options Installed
PD6400-6H0	PD6400-7H0	No options
PD6400-6H2	PD6400-7H2	2 relays (PD1102*)
PD6400-6H3	PD6400-7H3	4-20 mA output (PD1103*)
PD6400-6H4	PD6400-7H4	4 relays (PD1104*)
PD6400-6H5	PD6400-7H5	2 relays & 4-20 mA output (PD1105*)
PD6400-6H7	PD6400-7H7	4 relays & 4-20 mA output (PD1107*)
*Model number for replacement option card.		

Accessories

Model	Description
PDA1002	DIN rail mounting kit for two expansion modules
PDA1004	4 SPST (Form A) relays
PDA1011	Dual 4-20 mA expansion module
PDA1044	4 digital inputs & 4 digital outputs (2 may be connected)
PDA1232	RS-232 serial adapter
PDA1485	RS-485 serial adapter
PDA7485-I	RS-232 to RS-422/485 isolated converter
PDA7485-N	RS-232 to RS-422/485 non-isolated converter
PDA8232-N	USB to RS-232 non-isolated converter
PDA8485-I	USB to RS-422/485 isolated converter
PDA8485-N	USB to RS-422/485 non-isolated converter
PDX6901	Suppressor (snubber): 0.01 μ F/470 Ω , 250 VAC

Specifications

Except where noted all specifications apply to operation at +25°C.

General

Display	Line 1: 0.60" (15 mm) high, red LEDs Line 2: 0.46" (12 mm) high, red LEDs 6 digits each (-99999 to 999999), with lead zero blanking
Display Intensity	Eight user selectable intensity levels
Display Update Rate	5/second (200 ms)
Overrange	Display flashes 999999
Underrange	Display flashes -99999
Display Assignment	Display lines 1 & 2 may be assigned to process values for Channels A (Ch-A, current), V (Ch-V, voltage), or P (Ch-P, apparent power); toggle between (Ch-A & Ch-V, Ch-A & Ch-P, Ch-V & Ch-P, and Ch-A, Ch-V, & Ch-P); relay set points; max and/or min values for Ch-A, Ch-V, or Ch-P; CH-A and units; Ch-V and units; Ch-P and units; or Modbus input. Display line 2 may also be set to show engineering units or be off, with no display.
Programming Methods	Four front panel buttons, digital inputs, PC and MeterView Pro software, or Modbus registers.
Noise Filter	Programmable from 2 to 199 (0 will disable filter)
Filter Bypass	Programmable from 0.1 to 99.9% of calibrated span
Recalibration	All ranges are calibrated at the factory. Recalibration is recommended at least every 12 months.
Max/Min Display	Max/min readings reached by each displayed input type are stored until reset by the user or until power to the meter is cycled.
Password	Three programmable passwords restrict modification of programmed settings. Pass 1: Allows use of function keys and digital inputs Pass 2: Allows use of function keys, digital inputs and editing set/reset points Pass 3: Restricts all programming, function keys, and digital inputs.
Non-Volatile Memory	All programmed settings are stored in non-volatile memory for a minimum of ten years if power is lost.
Power Options	85-265 VAC 50/60 Hz, 90-265 VDC, 20 W max or 12-24 VDC $\pm$ 10%, 15 W max Powered over USB for configuration only
Fuse	Required external fuse: UL Recognized, 5 A max, slow blow; up to 6 meters may share one 5 A fuse
Isolation	500 V AC/DC potential allowed between voltage and current input channels. Channels isolated by 3 M Ω impedance 4 kV input/output-to-power line 500 V input-to-output or output-to-P+ supply

Overvoltage Category	Installation Overvoltage Category II: Local level with smaller transient overvoltages than Installation Overvoltage Category III.
Environmental	Operating temperature range: -40 to 65°C Storage temperature range: -40 to 85°C Relative humidity: 0 to 90% non-condensing
Connections	Removable screw terminal blocks accept 12 to 22 AWG wire, RJ45 for external relays, digital I/O, and serial communication adapters.
Enclosure	1/8 DIN, high impact plastic, UL 94V-0, color: black
Mounting	1/8 DIN panel cutout required: 3.622" x 1.772" (92 mm x 45 mm) Two panel mounting bracket assemblies are provided.
Tightening Torque	Screw terminal connectors: 5 lb-in (0.56 Nm)
Overall Dimensions	4.68" x 2.45" x 5.64" (119 mm x 62 mm x 143 mm) (W x H x D)
Weight	9.5 oz (269 g)
Warranty	3 years parts & labor

Voltage and Current Inputs

High Voltage Input	One high voltage input (Channel V) 0-300 VDC or VAC; Switch Selectable, Modbus PV (Slave)
High Current Input	One high current input (Channel A) 0-5 AAC or ADC; Switch Selectable, Modbus PV (Slave)
Channels	Channel A, Channel V, Channel P (Math Channel for Apparent Power)
Ac/Dc Selection	Switch selectable for AC or DC inputs. Channels A and V share AC/DC selection.
Apparent Power Math	Apparent power P calculated as $P = ((A * V + C) * F$
Programmable Constants	Constant C (Adder): -99.999 to 999.999, default: 0.000 Constant F (Factor): 0.001 to 999.999, default: 1.000
Accuracy	ADC: 0.03% Full Scale $\pm$ 1 count, AAC: 0.1% Full Scale $\pm$ 1 count, VDC: 0.05% Full Scale $\pm$ 1 count, VAC: 0.15% Full Scale $\pm$ 1 count, square root & programmable exponent accuracy range: 10-100% of calibrated span
Temperature Drift	0.005% of calibrated span/°C max from -40 to 65°C ambient
Signal Input Conditioning	Linear, square root, programmable exponent, or round horizontal tank volume calculation
Multi-Point Linearization	2 to 32 points for Channel A and V
Low-Flow Cutoff	0-999999 (0 disables cutoff function). Independent for Channel A and V.

Decimal Point	Up to five decimal places or none: <i>dddddd, dddd, dddd, ddd, dd, or dddddd</i>		
Calibration Range	Input Channel	Input Range	Minimum Span Input 1 & Input 2
	A	+/- 0-5 ADC 0-5 AAC	+/- 0.005 ADC 0.010 AAC
	V	+/- 0-300 VDC 0-300 VAC	+/- 0.1 VDC 0.3 VAC
	An error message will appear if the input 1 and input 2 signals are too close together.		
Input Impedance	Voltage Input: Greater than 3 MΩ Current Input: 50 - 100 Ω		
Input Overload	Voltage input protected up to 500 VDC Current input protected up to 10 A by a 10A/300V fast acting non-resettable fuse Fuse is NOT resettable after a fault; unit must be factory reconditioned.		
F4 Digital Input Contacts	3.3 VDC on contact. Connect normally open contacts across F4 to COM.		
F4 Digital Input Logic Levels	Logic High: 3 to 5 VDC Logic Low: 0 to 1.25 VDC		
Relays			
Rating	2 or 4 SPDT (Form C) internal and/or 4 SPST (Form A) external; rated 3 A @ 30 VDC and 125/250 VAC resistive load; 1/14 HP (≈ 50 W) @ 125/250 VAC for inductive loads		
Noise Suppression	Noise suppression is recommended for each relay contact switching inductive loads; see page 13 for details.		
Relay Assignment	Each relay independently assigned to Ch-A, Ch-V, CH-P, or Modbus		
Deadband	0-100% of span, user programmable		
High Or Low Alarm	User may program any alarm for high or low trip point. Unused alarm LEDs and relays may be disabled (turn off).		
Relay Operation	Automatic (non-latching) Latching (required manual acknowledge) Pump alternation control (2 to 8 relays) Sampling (based on time) Off (disable unused relays and enable Interlock feature) Manual on/off control mode		
Relay Reset	User selectable via front panel buttons, digital inputs, or PC - Automatic reset only (non-latching), when the input passes the reset point. - Automatic + manual reset at any time (non-latching) - Manual reset only, at any time (latching) - Manual reset only after alarm condition has cleared (L) <i>Note: Front panel button or digital input may be assigned to acknowledge relays programmed for manual reset.</i>		

Time Delay	0 to 999.9 seconds, on & off relay time delays Programmable and independent for each relay
Fail-Safe Operation	Programmable and independent for each relay. <i>Note: Relay coil is energized in non-alarm condition. In case of power failure, relay will go to alarm state.</i>
Break Condition Operation	Relay condition when sensor break detected. Programmable independently for each relay as On, Off, or Ignore (maintain last condition).
Auto Initialization	When power is applied to the meter, relays will reflect the state of the input to the meter.

Isolated 4-20 mA Transmitter Output

Output Source	Process channel A, V, or P, max or min for channel A, V, or highest or lowest max or min of A and V, set points 1-8, Modbus input, or manual control mode		
Scaling Range	1.000 to 23.000 mA for any display range		
Calibration	Factory calibrated: 4.000 to 20.000 = 4-20 mA output		
Analog Out Programming	23.000 mA maximum for all parameters: Overrange, underrange, max, min, and break		
Accuracy	$\pm 0.1\%$ of span ± 0.004 mA		
Temperature Drift	0.4 μ A/ $^{\circ}$ C max from 0 to 65 $^{\circ}$ C ambient, 0.8 μ A/ $^{\circ}$ C max from -40 to 0 $^{\circ}$ C ambient <i>Note: Analog output drift is separate from input drift.</i>		
Isolated Transmitter Power Supply	Terminals I+ & R: 24 VDC $\pm 10\%$ @ 40mA. May be used to power the 4-20 mA output or other devices. Refer to Figure 5 on page 10 and Figure 19 on page 14.		
External Loop Power Supply	35 VDC maximum		
Output Loop Resistance	Power supply	Minimum	Maximum
	24 VDC	10 Ω	700 Ω
	35 VDC (external)	100 Ω	1200 Ω

Modbus® RTU Serial Communications

Slave Id	1 – 247 (Meter address)
Baud Rate	300 – 19,200 bps
Transmit Time Delay	Programmable between 0 and 199 ms
Data	8 bit (1 start bit, 1 or 2 stop bits)
Parity	Even, Odd, or None with 1 or 2 stop bits
Byte-To-Byte Timeout	0.01 – 2.54 second
Turn Around Delay	Less than 2 ms (fixed)

MeterView Pro

System Requirements	Microsoft® Windows® XP/Vista/7/8/10
Communications	USB 2.0 (Standard USB A to Micro USB B)
Configuration	Configure meters one at a time

Compliance Information

Safety

UL & c-UL Listed	USA & Canada UL 508 Industrial Control Equipment
UL File Number	E160849
Front Panel	UL Type 4X, NEMA 4X, IP65; panel gasket provided
Low Voltage Directive	EN 61010-1:2010 Safety requirements for measurement, control, and laboratory use

Electromagnetic Compatibility

Emissions	EN 55022:2010 Class A ITE emissions requirements
Radiated Emissions	Class A
AC Mains Conducted Emissions	Class A
Immunity	EN 61326-1:2013 Measurement, control, and laboratory equipment EN 61000-6-2:2005 EMC heavy industrial generic immunity standard
RFI - Amplitude Modulated	80 -1000 MHz 10 V/m 80% AM (1 kHz) 1.4 - 2.0 GHz 3 V/m 80% AM (1 kHz) 2.0 - 2.7 GHz 1 V/m 80% AM (1 kHz)
Electrical Fast Transients	±2kV AC mains, ±1kV other
Electrostatic Discharge	±4kV contact, ±8kV air
RFI - Conducted	10V, 0.15-80 MHz, 1kHz 80% AM
AC Surge	±2kV Common, ±1kV Differential
Surge	1KV (CM)
Power-Frequency Magnetic Field	30 A/m 70%V for 0.5 period
Voltage Dips	40%V for 5 & 50 periods 70%V for 25 periods
Voltage Interruptions	<5%V for 250 periods

Note:

Testing was conducted on PD6000 Series meters installed through the covers of grounded metal enclosures with cable shields grounded at the point of entry representing installations designed to optimize EMC performance.

Safety Information

 CAUTION <i>Read complete instructions prior to installation and operation of the meter.</i>	 WARNING! <i>Risk of electric shock or personal injury.</i>
 WARNING! <i>Hazardous voltages exist within enclosure. Installation and service should be performed only by trained service personnel.</i>	

Installation

There is no need to remove the meter from its case to complete the installation, wiring, and setup of the meter for most applications.

Unpacking

Remove the meter from box. Inspect the packaging and contents for damage. Report damages, if any, to the carrier.

If any part is missing or the meter malfunctions, please contact your supplier or the factory for assistance.

Panel Mounting Instructions

- Prepare a standard 1/8 DIN panel cutout – 3.622" x 1.772" (92 mm x 45 mm). Refer to Figure 1 below, for more details.
- Clearance: allow at least 6.0" (152 mm) behind the panel for wiring.
- Panel thickness: 0.04" - 0.25" (1.0 mm - 6.4 mm).
Recommended minimum panel thickness to maintain Type 4X rating: 0.06" (1.5 mm) steel panel, 0.16" (4.1 mm) plastic panel.
- Remove the two mounting brackets provided with the meter (back-off the two screws so that there is ¼" (6.4 mm) or less through the bracket. Slide the bracket toward the front of the case and remove).
- Insert meter into the panel cutout.
- Install mounting brackets and tighten the screws against the panel. To achieve a proper seal, tighten the mounting bracket screws evenly until meter is snug to the panel along its short side. **DO NOT OVER TIGHTEN**, as the rear of the panel may be damaged.




Figure 1. 1/8 DIN Panel Cutout Dimensions




Figure 2. Panel Mounting Details

Mounting Dimensions




Figure 3. Meter Dimensions - Side View




Figure 4. Meter Dimensions - Top View

Connections

All connections are made to removable screw terminal connectors located at the rear of the meter.



Caution!

Use copper wire with 60°C or 60/75°C insulation for all line voltage connections. Observe all safety regulations. Electrical wiring should be performed in accordance with all applicable national, state, and local codes to prevent damage to the meter and ensure personnel safety.

Connectors Labeling

The connectors' label, affixed to the meter, shows the location of all connectors available with requested configuration.



Warning!

Do not connect any equipment other than Precision Digital's expansion modules, cables, or meters to the RJ45 M-LINK connector. Otherwise damage will occur to the equipment and the meter.




Figure 5. Connector Labeling for Fully Loaded PD6400

Power Connections

Power connections are made to a two-terminal connector labeled POWER on Figure 5. The meter will operate regardless of DC polarity connection. The + and - symbols are only a suggested wiring convention.




Figure 6. Power Connections

Signal Connections

Signal connections are made to a four-terminal connector labeled SIGNAL on Figure 5. The I+ and I- terminals are used for Channel A (CH-A) as the current input terminals. The V+ and V- terminals are used for Channel V (CH-V) as the voltage input terminals.

In addition to the signal connections, the switch labeled TYPE on Figure 5 must be set to AC (alternating current) or DC (direct current) to accept the corresponding type of voltage and current signals.

Voltage Input

The following figures show examples of connecting the meter for a voltage input. Note that in addition to the connections, the AC/DC type switch must also be set.




Figure 7. AC Voltage Input Connection




Figure 8. DC Voltage Input Connections

Current Input

The following figures show examples of connecting the meter for a current input. Note that in addition to the connections, the AC/DC type switch must also be set.




Figure 9. AC Current Connections




Figure 10. AC Current Transformer Connections




Figure 11. DC Current Connections

Current and Voltage Input

The following figures show examples of connecting the meter for both current and voltage input. Note that in addition to the connections, the AC/DC type switch must also be set.




Figure 12. AC Current and Voltage Connections




Figure 13. AC Current Transformer and Voltage Connections




Figure 14. DC Current and Voltage Connections

Modbus RTU Serial Communications

Serial communications connection is made to an RJ45 connector labeled M-LINK on Figure 5. For interfacing to the PROVu®, use the PDA1232 for RS-232 or the PDA1485 for RS-485. The same port is used for interfacing with all expansion modules (e.g. external relays, digital I/O).

Relay Connections

Relay connections are made to two six-terminal connectors labeled RELAY1 – RELAY4 on Figure 5. Each relay's C terminal is common only to the normally open (NO) and normally closed (NC) contacts of the corresponding relay. The relays' C terminals should not be confused with the COM (common) terminal of the INPUT SIGNAL connector.




Figure 15. Relay Connections

Switching Inductive Loads

The use of suppressors (snubbers) is strongly recommended when switching inductive loads to prevent disrupting the microprocessor's operation. The suppressors also prolong the life of the relay contacts. Suppression can be obtained with resistor-capacitor (RC) networks assembled by the user or purchased as complete assemblies. Refer to the following circuits for RC network assembly and installation:




Figure 16. AC and DC Loads Protection


Choose R and C as follows:

R: 0.5 to 1 Ω for each volt across the contacts

C: 0.5 to 1 μF for each amp through closed contacts

Notes:

1. Use capacitors rated for 250 VAC.
2. RC networks may affect load release time of solenoid loads. Check to confirm proper operation.
3. Install the RC network at the meter's relay screw terminals. An RC network may also be installed across the load. Experiment for best results.



Use a diode with a reverse breakdown voltage two to three times the circuit voltage and forward current at least as large as the load current.

Figure 17. Low Voltage DC Loads Protection

RC Networks Available from Precision Digital

RC networks are available from Precision Digital and should be applied to each relay contact switching an inductive load. Part number: PDX6901.

Note: Relays are de-rated to 1/14th HP (50 watts) with an inductive load.

F4 Digital Input Connections

A digital input, F4, is standard on the meter. This digital input connected with a normally open closure across F4 and COM, or with an active low signal applied to F4.




Figure 18. F4 Digital Input Connections

4-20 mA Output Connections

Connections for the 4-20 mA transmitter output are made to the connector terminals labeled MA OUT. The 4-20 mA output may be powered internally or from an external power supply.




Figure 19. 4-20 mA Output Connections

Analog Output Transmitter Power Supply

The internal 24 VDC power supply powering the analog output may be used to power other devices, if the analog output is not used. The I+ terminal is the +24 V and the R terminal is the return.

External Relay, Analog Output, & Digital I/O Connections

The relay, analog out, and digital I/O expansion modules PDA1004, PDA1011, and PDA1044 are connected to the meter using a CAT5 cable provided with each module. The two RJ45 connectors on the expansion modules are identical and interchangeable; they are used to connect additional modules to the system.

Note: The jumper located between the RJ45 connectors of the PDA1044 must be removed on the second digital I/O module in order for the system to recognize it as module #2.



Warning!

Do not connect or disconnect the expansion modules with the power on!
More detailed instructions are provided with each optional expansion module.

Interlock Relay Feature

As the name implies, the interlock relay feature reassigns one, or more, alarm/control relays for use as interlock relay(s). Interlock contact(s) are wired to digital input(s) and trigger the interlock relay. This feature is enabled by configuring the relay, and relative digital input(s) (see page 33). In one example, dry interlock contacts are connected in series to one digital input which will be used to force on (energize) the assigned interlock power relay when all interlock contacts are closed (safe). The interlock relay front panel LED flashes when locked out. The interlock relay would be wired in-series with the load (N/O contact). See below.




Figure 20. Interlock Connections

Setup and Programming

The meter is factory calibrated prior to shipment to read in amps and volts. The calibration equipment is certified to NIST standards.

Overview

There are no jumpers to set for the meter input selection.

Setup and programming is done through the front panel buttons.

After power and input signal connections have been completed and verified, apply power to the meter.

Front Panel Buttons and Status LED Indicators



Button Symbol	Description	LED	Status
	Menu	1-8	Alarm 1-8 indicator
	Right arrow/F1	1-8 M	Flashing: Relay in manual control mode
	Up arrow/F2	A V P	Channel displayed
	Enter/F3	1-4	Flashing: Relay interlock switch open
Notes: F4 is a digital input. Alarms 5-8 are enabled when relay expansion module installed.		Note: LEDs for relays in manual mode flash with the "M" LED every 10 seconds.	

- Press the Menu button to enter or exit the Programming Mode at any time.
- Press the Right arrow button to move to the next digit during digit or decimal point programming.
- Press or hold the Up arrow button to scroll through the menus, decimal point, or to increment the value of a digit.
- Press the Enter button to access a menu or to accept a setting.
- Press and hold the Menu button for three seconds to access the advanced features of the meter.

MeterView® Pro Software


The meter can also be programmed using the PC-based MeterView Pro software included with the meter. This software can be installed on any Microsoft® Windows® (XP/Vista/7/8/10) computer by connecting the meter's onboard USB. The meter is powered by the USB connection, so there is no need to wire anything prior to programming the meter, though USB is intended only for meter configuration.

MeterView Pro Installation


1. Connect one end of the provided USB cable to the meter and the other end to the computer. The computer will automatically install the driver software it needs to talk to the meter.

Only one meter may be connected at a time.

Attaching multiple meters will cause a conflict with the meter software.



2. Once the driver is installed, an AutoPlay dialog should appear for the drive "MAINSTAL." Click "Open folder to view files." If the computer does not display an AutoPlay dialog for the drive "MAINSTAL," you should open My Computer and double-click on the drive labeled "MAINSTAL."
3. Double-click on the file named "MAStart." The program will open a few windows and install two programs on your computer. Simply follow the onscreen instructions until you see one of the dialogs below. If you receive a "User Account Control" warning, click "Yes."
4. If there is an update available, click the "Update" button to install the new version. Otherwise, click "Configure" to begin programming your meter.



Note: If you decide to update your MeterView Pro software, once the installation has completed, you will be asked if you want to update the setup files located on the meter itself. This way, you will always have the most current version on the meter for future installs.



Warning!

Do not unplug the meter while the new installation files are being written to it. The meter will display μA during the process and you will receive an onscreen notification once the process is complete.

Data logging for one meter at a time is available with MeterView Pro software. More advanced data acquisition may be accomplished by using any Modbus RTU compliant software. Additional information regarding configuration and monitoring of the meter using MeterView Pro software is available online.

Display Functions & Messages

The following table shows the main menu functions and messages in the order they appear in the menu.

Display	Parameter	Action/Setting Description
SEtUP	Setup	Enter Setup menu
units	Unit	Select the display units/tags
Ch-A*	Unit	Set unit or tag for channel A (*or V or P)
dEc Pt	Decimal point	Set decimal point
Ch-A*	Decimal point	Set decimal point for channel A (*or V or P)
InCAL	Input calibration	Enter the Input Calibration menu
Ch-A*	Input A	Set input type for channel A (*or V)
SCALE A	Scale A	Enter the Scale menu for channel A
InP 1	Input 1	Scale input 1 signal or program input 1 value
d.s 1	Display 1	Program display 1 value
InP 2	Input 2	Scale input 2 signal or program input 2 value (up to 32 points)
d.s 2	Display 2	Program display 2 value (up to 32 points)
Error	Error	Error, scaling not successful, check signal or programmed value
CAL A	Calibrate A	Enter the Calibration menu for channel A
InP 1	Input 1	Calibrate input 1 signal or program input 1 value
d.s 1	Display 1	Program display 1 value
InP 2	Input 2	Calibrate input 2 signal or program input 2 value (up to 32 points)
d.s 2	Display 2	Program display 2 value (up to 32 points)
Error	Error	Error, calibration not successful, check signal or programmed value
dSPLY	Display	Enter the Display menu
Line 1	Line 1	Assign the upper display parameter
Line 2	Line 2	Assign the lower display parameter
d Ch-A	Display Ch-A	Assign display to channel A
d Ch-V	Display Ch-V	Assign display to channel V
d Ch-P	Display Ch-P	Assign display to channel P (P=A*V)

Display	Parameter	Action/Setting Description
d AU	Display AV	Alternate display of channel A & V
d AP	Display AP	Alternate display of channel A & P
d UP	Display VP	Alternate display of channel V & P
d AUP	Display AVP	Alternate display of channel A, V, & P
d SEt 1*	Display set 1*	Displays relay 1 (*through 8) set point.
d Hi-A	Display high A	Display high value of channel A
d Lo-A	Display low A	Display low value of channel A
d HL-A	Display hi/low A	Alternate between high/low value of channel A
d Hi-V	Display high V	Display high value of channel V
d Lo-V	Display low V	Display low value of channel V
d HL-V	Display high/low V	Alternate between high/low value of channel V
d Hi-P	Display high P	Display high value of channel P
d Lo-P	Display low P	Display low value of channel P
d HL-P	Display high/low P	Alternate between high/low value of channel P
d A-u	Display A and units/tags	Alternate display of channel A and the unit/tag
d V-u	Display V and units/tags	Alternate display of channel V and the unit/tag
d P-u	Display P and units/tags	Alternate display of channel P and the unit/tag
Modbus	Display Modbus	Display Modbus input register
d OFF*	Display off	Display blank display (*line 2 only)
d units*	Display unit	Display line 1 channel units (*line 2 only)
d IntY	Display intensity	Set display intensity level from 1 to 8
RELAY	Relay	Enter the Relay menu
ASSIGN	Assignment	Assign relays to channels or Modbus


Display	Parameter	Action/Setting Description
RS 1*	Assign 1*	Relay 1 (*through 8) assignment
Ch-A*	Channel A*	Assign relay to channel A (*or V or P)
Modbus	Modbus	Assign relay to Modbus register
Relay 1*	Relay 1*	Relay 1 (*through 8) setup
Action 1*	Action 1*	Set relay 1 (*through 8) action
Auto	Automatic	Set relay for automatic reset
Auto-manual	Auto-manual	Set relay for auto or manual reset any time
Latching	Latching	Set relay for latching operation
Latching-cleared	Latching-cleared	Set relay for latching operation with manual reset only after alarm condition has cleared
Alternate	Alternate	Set relay for pump alternation control
Sample	Sample	Set relay for sample time trigger control
Off	Off	Turn relay off
Fail-safe	Fail-safe	Enter Fail-safe menu
Fail-safe 1*	Fail-safe 1*	Set relay 1 (*through 8) fail-safe operation
On	On	Enable fail-safe operation
Off	Off	Disable fail-safe operation
Delay	Delay	Enter relay Time Delay menu
Delay 1*	Delay 1*	Enter relay 1 (*through 8) time delay setup
On 1	On 1	Set relay 1 On time delay
Off 1	Off 1	Set relay 1 Off time delay
Delay 2	Delay 2	Enter relays 2-8 time delay setup
Loop break	Loop break	Set relay condition if loop break detected
Loop break 1*	Loop break 1*	Set relay 1 (*through 8) break condition

Display	Parameter	Action/Setting Description
Ignore	Ignore	Ignore loop break condition (Processed as a low signal condition)
On	On	Relay goes to alarm condition when loop break detected
Off	Off	Relay goes to non-alarm condition when loop break detected
Analog output	Analog output	Enter the Analog output scaling menu
Analog output 1*	Analog output 1*	Analog Output source channel (*1-3)
Display 1	Display 1	Program display 1 value
Output 1	Output 1	Program output 1 value (e.g. 4.000 mA)
Display 2	Display 2	Program display 2 value
Output 2	Output 2	Program output 2 value (e.g. 20.000 mA)
Reset	Reset	Press Enter to access the Reset menu
Reset high	Reset high	Press Enter to reset max display
Reset low	Reset low	Press Enter to reset min display
Reset high & low	Reset high & low	Press Enter to reset max & min displays
Control	Control	Enter Control menu
Auto	Automatic	Press Enter to set meter for automatic operation
Manual	Manual	Press Enter to manually control relays or analog output operation
Password	Password	Enter the Password menu
Password 1*	Password 1*	Set or enter Password 1 (*through 3)
Unlocked	Unlocked	Program password to lock meter
Locked	Locked	Enter password to unlock meter
999999-999999	Flashing	Over/under range condition

Main Menu

The main menu consists of the most commonly used functions: *Reset*, *Control*, *Setup*, and *Password*.

- Press Menu button to enter Programming Mode then press the Up arrow button to scroll main menu.
- Press Menu at any time to exit and return to Run Mode. Changes made to settings prior to pressing Enter are not saved.
- Changes to the settings are saved to memory only after pressing Enter.
- The display moves to the next menu every time a setting is accepted by pressing Enter.




Setting Numeric Values

The numeric values are set using the Right and Up arrow buttons. Press Right arrow to select next digit and Up arrow to increment digit value.

The digit being changed is displayed brighter than the rest.

Press and hold up arrow to auto-increment the display value.

Press the Enter button at any time to accept a setting or Menu button to exit without saving changes.




Setting Up the Meter (SEtUP)

The *Setup* menu is used to select:

1. Input signal the meter will accept for channel A and channel V
2. Units for A, V, and P
3. Decimal point position for A, B, and C
4. Program the meter using the Scale or Calibrate functions
5. Display parameter and intensity
6. Relay assignment and operation
7. 4-20 mA analog output scaling

Press the Menu button to exit at any time.




Setting the Decimal Point (dEc Pt)

The decimal point may be set with up to five decimal places or with no decimal point at all.

Pressing the Right arrow moves the decimal point one place to the right until no decimal point is displayed, and then it moves to the leftmost position.

There are three decimal points to set up for three channels: Ch-A, Ch-V, and Ch-P.

After the decimal points are set up, the meter moves to the *Program* menu.



Setting the Input Calibration (InCAL)


It is **very important** to read the following information, before proceeding to program the meter:

- The meter is factory calibrated prior to shipment to read in amps and volts. The calibration equipment is certified to NIST standards.
- Use the *Scale* menu to scale the current and voltage inputs. A calibrated signal source is not needed to scale the meter.
- Use the *Calibrate* menu to apply a signal from a calibrator or other live signal source.

The *Program* menu contains the *Scale* and the *Calibrate* menus for channels A & V.

The process inputs may be calibrated or scaled to any display value within the range of the meter.

Note: The Scale and Calibrate functions are exclusive of each other. The meter uses the last function programmed. Only one of these methods can be employed at a time. The Scale and Calibrate functions can use up to 32 points (default is 2). The number of points should be set in the Advanced Menu under the menu selection prior to scaling and calibration of the meter, see page 40 for details.



Multi-Point Linearization (LINEAR)

The process inputs may be calibrated or scaled to any display value within the range of the meter. The meter is set up at the factory for 2-point linear calibration.


Up to 32 linearization points may be selected. See page 40 for details.

Scaling the Meter without a Signal Source


The voltage and current inputs can be scaled to display the process variables in engineering units.

A signal source is not needed to scale the meter; simply program the inputs and corresponding display values.

Scaling the Meter for Channel A (SCAL-A)



Scaling the Meter for Channel V (SCAL-U)



For instructions on how to program numeric values see *Setting Numeric Values*, page 20.

Error Message (Error)

An error message indicates that the calibration or scaling process was not successful.

After the error message is displayed, the meter reverts to input 2 during calibration or scaling and to input 1 during internal calibration, allowing the appropriate input signal to be applied or programmed.

The error message might be caused by any of the following conditions:

1. Input signal is not connected to the proper terminals or it is connected backwards.
2. Wrong signal selection in *Setup* menu.
3. Minimum input span requirements not maintained.
4. Input 1 signal inadvertently applied to calibrate input 2.

Minimum Input Span

The minimum input span is the minimum difference between input 1 and input 2 signals required to complete the calibration or scaling of the meter.

Input Range	Input 1 & Input 2 Span
+/- 0-5 ADC	+/- 0.005 ADC
0-5 AAC	0.010 AAC
+/- 0-300 VDC	+/- 0.1 VDC
0-300 VAC	0.3 VAC

Calibrating the Meter with External Source


To scale the meter without a signal source, refer to *Scaling the Meter without a Signal Source*, page 22.

Warm up the meter for at least 15 minutes before performing calibration to ensure specified accuracy.

The meter can be calibrated to display the process variable in engineering units by applying the appropriate input signal and following the calibration procedure.

The use of a calibrated signal source is strongly recommended to calibrate the meter.

Calibrating the Meter for Channel A (CAL-R) Calibrating the Meter for Channel V (CAL-U)




Setting the Display Parameter & Intensity (d5PLAY)

Display line 1 (LINE 1) can be programmed to display:

1. Process value Ch-A
2. Process value Ch-V
3. Process value Ch-P
4. Toggle between Ch-A & Ch-V, Ch-A & Ch-P, Ch-V & Ch-P, and Ch-A, Ch-V, & Ch-P
5. Relay set points
6. Max & min values for each channel
7. Toggle between Channel & units
8. Modbus input

Display line 2 (LINE 2) can be programmed to display:

1. Process value Ch-A
2. Process value Ch-V
3. Process value Ch-P
4. Toggle between Ch-A & Ch-V, Ch-A & Ch-P, Ch-V & Ch-P, and Ch-A, Ch-V, & Ch-P
5. Relay set points
6. Max & min values for each channel
7. Toggle between Channel & units
8. Modbus input
9. Off (no display)
10. Engineering units or custom legends



Display Intensity: The meter has eight display intensity levels to give the best performance under various lighting conditions. Select intensity 8 for outdoor applications. The default intensity setting is 8.

After setting up the input and display, press the Menu button to exit programming and skip the rest of the setup menu.

The displays can be set up to read channels A, V, or P, toggle between A & V, V & P, A & P, A & V & P, toggle between channels A, V, or P & units, the max/min of any of the channels, including the power channel (P), set points, or the Modbus input. In addition to the parameters available on display line 1, line 2 can display Engineering units or it could be turned off.

Setting the Input Units or Custom Tags (ۛۛۛ5)

Enter the input unit or custom tag that will be displayed if alternating process input and units is selected in the ۛۛۛ5 menu, or ۛ ۛۛۛۛ is selected as the display line 2 parameter. See the flow chart on page 24 to access the display menu to show the unit or tag on line 2. The engineering units or custom legends can be set using the following 7-segment character set:

Display	Character	Display	Character	Display	Character	Display	Character
0	0	C	C	K	K	V	V
1	1	c	c	L	L	w	w
2	2	d	d	m	m	X	X
3	3	E	E	n	n	Y	Y
4	4	F	F	O	O	Z	Z
5	5	G	G	o	o	-	-
6	6	g	g	P	P	/	/
7	7	H	H	q	q	[	]
8	8	h	h	r	r	]	[
9	9	l	l	S	S	=	=
A	A	i	i	t	t	°	Degree(<)
b	b	J	J	u	u		Space

Notes: Degree symbol represented by (<) if programming with MeterView® Pro. The letters “m” and “w” use two 7-segment LEDs each; when selected the characters to the right are shifted one position.

Press and hold up arrow to auto-scroll the characters in the display.

Setting the Relay Operation (rELAY)


This menu is used to set up the assignment and operation of the relays.



Caution!


During setup, the relays do not follow the input and they will remain in the state found prior to entering the Relay menu.

1. Relay assignment
 - a. Channel A
 - b. Channel V
 - c. Channel P (Power channel)
 - d. Modbus
2. Relay action
 - a. Automatic reset only (non-latching)
 - b. Automatic + manual reset at any time (non-latching)
 - c. Latching (manual reset only)
 - d. Latching with Clear (manual reset only after alarm condition has cleared)
 - e. Pump alternation control (automatic reset only, for level applications unrelated to voltage and current monitoring)
 - f. Sampling (the relay is activated for a user-specified time)
 - g. Off (relay state controlled by Interlock feature)
3. Set point
4. Reset point
5. Fail-safe operation
 - a. On (enabled)
 - b. Off (disabled)
6. Time delay
 - a. On delay (0-999.9 seconds)
 - b. Off delay (0-999.9 seconds)
7. Relay action for loss (break) of 4-20 mA input (ignore, on, off)



Setting the Relay Assignment (ASSIGN)

The relays may be assigned to their the current or voltage input channels, the apparent power channel P, or Modbus® input.




Setting the Relay Action


Operation of the relays is programmed in the *Action* menu. The relays may be set up for any of the following modes of operation:

1. Automatic reset (non-latching)
2. Automatic + manual reset at any time (non-latching)
3. Latching (manual reset only, at any time)
4. Latching with Clear (manual reset only after alarm condition has cleared)
5. Pump alternation control (automatic reset only, for level applications unrelated to voltage and current monitoring)
6. Sampling (the relay is activated for a user-specified time)
7. Off (relay state controlled by Interlock feature)

The following graphic shows relay 1 action setup; relay 2-8 are set up in a similar fashion.



Programming Set and Reset Points



High alarm indication: program set point above reset point.
 Low alarm indication: program set point below reset point.
 The deadband is determined by the difference between set and reset points. Minimum deadband is one display count. If the set and reset points are programmed with the same value, the relay will reset one count below the set point.
Note: Changes are not saved until the reset point has been accepted.

Setting Fail-Safe Operation

In fail-safe mode of operation, the relay coil is energized when the process variable is within safe limits and the relay coil is de-energized when the alarm condition exists. The fail-safe operation is set independently for each relay. Select **on** to enable or select **oFF** to disable fail-safe operation.

Programming Time Delay

The *On* and *Off* time delays may be programmed for each relay between 0 and 999.9 seconds. The relays will transfer only after the condition has been maintained for the corresponding time delay.

The *On* time delay is associated with the set point.

The *Off* time delay is associated with the reset point.

Relay Action for Loss of Input (Loop Break)

The loop break feature is associated with the current or voltage input. Each relay may be programmed to go to one of the following conditions when the meter detects the loss of the input signal (i.e. < 25 mA):


1. Turn *On* (Go to alarm condition)
2. Turn *Off* (Go to non-alarm condition)
3. Ignore (Processed as a low signal condition)

Note: This is not a true loop break condition; if the signal drops below 25 mA, it is interpreted as a "loop break" condition.

Relay and Alarm Operation Diagrams


The following graphs illustrate the operation of the relays, status LEDs, and ACK button.

High Alarm Operation (Set > Reset)




For Manual reset mode, ACK can be pressed anytime to turn "off" relay. To detect a new alarm condition, the signal must go below the set point, and then go above it.

Low Alarm Operation (Set < Reset)




For Manual reset mode, ACK can be pressed anytime to turn "off" relay. For relay to turn back "on", signal must go above set point and then go below it.

High Alarm with Fail-Safe Operation (Set > Reset)




Note: Relay coil is energized in non-alarm condition. In case of power failure, relay will go to alarm state.

Low Alarm with Fail-Safe Operation (Set < Reset)



Note: Relay coil is energized in non-alarm condition. In case of power failure, relay will go to alarm state.

Relay Sampling Operation




When the signal crosses the set point, the relay trips and the sample time starts. After the sample time has elapsed, the relay resets. The cycle repeats every time the set point is crossed, going up for high alarms and going down for low alarms.

The sample time can be programmed between 0.1 and 5999.9 seconds.

Signal Loss or Loop Break Relay Operation

The following graph shows the loop break relay operation for a high alarm relay.




When the meter detects a break in the current or voltage loop, the relay will go to one of the following selected actions:

1. Turn *On* (Go to alarm condition)
2. Turn *Off* (Go to non-alarm condition)
3. Ignore (Processed as a low signal condition)

Time Delay Operation

The following graphs show the operation of the time delay function.



When the signal crosses the set point, the *On* time delay timer starts and the relay trips when the time delay has elapsed. If the signal drops below the set point (high alarm) before the time delay has elapsed, the *On* time delay timer resets and the relay does not change state. The same principle applies to the *Off* time delay.

Note: If "Automatic or Manual (R-n, Rn)" reset mode is selected, the LED follows the reset point and not the relay state when the relay is acknowledged.

Relay Operation Details

Overview

The relay capabilities of the meter expand its usefulness beyond simple indication to provide users with alarm and control functions. These capabilities include front panel alarm status LEDs as well as either 2 or 4 optional internal relays and/or 4 external relays expansion module. Typical applications include monitoring of high voltages and currents having to do with applications related to generators, voltage monitoring, current monitoring, or detecting locked rotor conditions. There are three basic ways the relays may typically be used:

1. High or Low Alarms with Latching or Non-Latching Relays
2. Simple On/Off Control with 100% Adjustable Deadband
3. Sampling (Based on Time)

Relays Auto Initialization

When power is applied to the meter, the front panel LEDs and alarm relays will reflect the state of the input to the meter. The following table indicates how the alarm LEDs and relays will react on power-up based on the set and reset points:

Alarm #	HI or LO Alarm	Set Point	Reset Point	Power-Up Reading	Relay & LED
1	HI	250	200	199	Off
2	LO	200	250	199	On
3	LO	100	150	199	Off
4	HI	150	100	199	On

Fail-Safe Operation

The following table indicates how the relays behave based on the fail-safe selection for each relay:

Note: NO = Normally Open, NC = Normally Closed. This refers to the condition of the relay contacts when the power to the meter is off.

Fail-Safe Selection	Non-Alarm State		Alarm State		Power Failure
	NO	NC	NO	NC	
Off	Open	Closed	Closed	Open	Relays go to non-alarm state
On	Closed	Open	Open	Closed	Relays go to alarm state

Front Panel LEDs

The LEDs on the front panel provide status indication for the following:

The meter is supplied with four alarm points that include front panel LEDs to indicate alarm conditions. This standard feature is particularly useful for alarm applications that require visual-only indication. The LEDs are controlled by the set and reset points programmed by the user. When the display reaches a set point for a high or low alarm, the corresponding alarm LED will turn on. When the display returns to the reset point the LED will go off. The front panel LEDs responds differently for latching and non-latching relays.

LED	Status	LED	Status
1	Alarm 1	5	Alarm 5
2	Alarm 2	6	Alarm 6
3	Alarm 3	7	Alarm 7
4	Alarm 4	8	Alarm 8

For non-latching relays, the LED is always off during normal condition and always on during alarm condition, regardless of the state of the relay (e.g. Relay acknowledged after alarm condition).

For latching relays, the alarm LEDs reflects the status of the relays, regardless of the alarm condition. The following tables illustrate how the alarm LEDs function in relation to the relays and the acknowledge button (Default: F3 key assigned to ACK).

Latching and Non-Latching Relay Operation

The relays can be set up for latching (manual reset) or non-latching (automatic reset) operation.

The On and Off terminology does not refer to the status of the relay's coil, which depends on the fail-safe mode selected.

Relay terminology for following tables

Terminology	Relay Condition
On	Alarm (Tripped)
Off	Normal (Reset)
Ack	Acknowledged



Warning!

In latching relay mode, latched relays will reset (unlatch) when power is cycled.

Non-Latching Relay (Relay)

In this application, the meter is set up for automatic reset (non-latching relay). Acknowledging the alarm while it is still present has no effect on either the LED or the relay. When the alarm finally goes away, the relay automatically resets and the LED also goes off.

Automatic reset only

Condition	LED	Relay
Normal	Off	Off
Alarm	On	On
Ack (No effect)	On	On
Normal	Off	Off

Non-Latching Relay (Relay)

In this application, the meter is set up for automatic and manual reset at any time (non-latching relay). The LED and the relay automatically reset when the meter returns to the normal condition.

The next time an alarm occurs, the operator acknowledges the alarm manually while the alarm condition still exists. This causes the relay to reset, but the LED stays on until the meter returns to the normal condition.

Automatic + manual reset at any time

Condition	LED	Relay
Normal	Off	Off
Alarm	On	On
Normal	Off	Off
Next Alarm	On	On
Ack	On	Off
Normal	Off	Off

Latching Relay (Relay)

In this application, the meter is set up for manual reset at any time. Acknowledging the alarm even if the alarm condition is still present resets the relay and turns off the LED.

Manual reset any time

Condition	LED	Relay
Normal	Off	Off
Alarm	On	On
Ack	Off	Off

Latching Relay (Relay)

In this application, the meter is set up for manual reset only after the signal passes the reset point (alarm condition has cleared). Acknowledging the alarm while it is still present has no effect on either the LED or the relay. When the alarm is acknowledged after it returns to the normal state, the LED and the relay go off. Notice that the LED remains on, even after the meter returns to the normal condition. This is because, for latching relays, the alarm LED reflects the status of the relay, regardless of the alarm condition.

Manual reset only after alarm condition has cleared

Condition	LED	Relay
Normal	Off	Off
Alarm	On	On
Ack (No effect)	On	On
Normal	On	On
Ack	Off	Off

Acknowledging Relays

There are two ways to acknowledge relays programmed for manual reset:

1. Via the programmable front panel function keys F1-F3 (Default: F3 assigned to ACK).
2. Remotely via a normally open pushbutton wired across one of the digital inputs and the +5 V terminals on the digital I/O modules, or using the F4 digital input, which is triggered with a contact closure to COM, or with an active low signal (see page 14).

When the ACK button or the assigned digital input is closed, all relays programmed for manual reset are acknowledged.




Figure 21. Acknowledge Relays w/Function Key or Digital Input


Pump Alternation Control Applications (Relay)

Pump alternation control is not recommended when using this meter, as it is used only in voltage and current monitoring applications, and not with rate, total, or batching applications.

Setting Up the Interlock Relay (Force On) Feature

Relays 1-4 can be set up as interlock relays. To set up the relays for the interlock feature:


1. Access the *Setup – Relay – Action* menu and set the action to off.



2. In the Advanced features – *User* menu program any of the digital inputs to *Force On* any of the internal relays (1-4).



3. Connect a switch or dry contact between the +5V terminal and the corresponding digital input (DI-1 to DI-4) terminal.



Interlock Relay Operation Example

Relays 1 & 2 are configured to energize (their front panel LEDs are off) when SW1 & SW2 switches (above) are closed. If the contacts to these digital inputs are opened, the corresponding front panel LEDs flash, indicating this condition. The processes being controlled by the interlock relay will stop, and will re-start only after the interlock relay is re-activated by the digital inputs (switches).


Note: If multiple digital inputs are assigned to the same relay, then the corresponding logic is (AND) – i.e. both switches must be closed to trip the relay.

Scaling the 4-20 mA Analog Output (Rout)

The 4-20 mA analog outputs can be scaled to provide a 4-20 mA signal for any display range selected. To select the channel and source assignments the analog outputs are assigned to, see *Analog Output Source* on page 41.

No equipment is needed to scale the analog outputs; simply program the display values to the corresponding mA output signal.

The *Analog Output* menu is used to program the 4-20 mA outputs based on display values.




Reset Menu (rESEt)

The *Reset* menu is used to reset the maximum or minimum reading (peak or valley) reached by the process; both may be reset at the same time by selecting “reset high & low” (rSE HL).

Control Menu (Contrl)

The *Control* menu is used to control the 4-20 mA analog output and the relays manually, ignoring the input. Each relay and analog output can be programmed independently for manual control. Selecting automatic control sets all relays and analog output for automatic operation.



Setting Up the Password (PASS)


The *Password* menu is used for programming three levels of security to prevent unauthorized changes to the programmed parameter settings.

Pass 1: Allows use of function keys and digital inputs
 Pass 2: Allows use of function keys, digital inputs and editing set/reset points
 Pass 3: Restricts all programming, function keys, and digital inputs.

Protecting or Locking the Meter

Enter the *Password* menu and program a six-digit password.

For instructions on how to program numeric values see *Setting Numeric Values*, page 20.




Making Changes to a Password Protected Meter

If the meter is password protected, the meter will display the message *Locd* (Locked) when the Menu button is pressed. Press the Enter button while the message is being displayed and enter the correct password to gain access to the menu. After exiting the programming mode, the meter returns to its password protected condition.

Disabling Password Protection

To disable the password protection, access the *Password* menu and enter the correct password twice, as shown below. The meter is now unprotected until a new password is entered.



If the correct six-digit password is entered, the meter displays the message *unLoc* (Unlocked) and the protection is disabled until a new password is programmed.

If the password entered is incorrect, the meter displays the message *Locd* (Locked) for about two seconds, and then it returns to Run Mode. To try again, press Enter while the *Locked* message is displayed.


Did you forget the password?

The password may be disabled by entering a master password once. If you are authorized to make changes, enter the master password 508655 to unlock the meter.

Advanced Features Menu

To simplify the setup process, functions not needed for most applications are located in the *Advanced Features* menu.

Press and hold the Menu button for three seconds to access the advanced features of the meter.



Advanced Features Menu & Display Messages

The following table shows the functions and messages of the *Advanced Features* menu in the order they appear in the menu.

Display	Parameter	Action/Setting
FILTER	Filter	Set noise filter value
Ch-A	Channel A	Set filter value for channel A
Ch-V	Channel V	Set filter value for channel V
bYPASS	Bypass	Set filter bypass value
Ch-A	Channel A	Set filter bypass value for channel A
Ch-V	Channel V	Set filter bypass value for channel V
round	Round	Set the rounding value for display variables
SErIAL	Serial	Set serial communication parameters
SLAVE ID	Slave ID	Set slave ID or meter address
baud	Baud rate	Select baud rate
Tr dLY	Transmit delay	Set transmit delay for serial communication
PARITY	Parity	Select parity Even, Odd, or None with 1 or 2 stop bits
t-byt	Time byte	Set byte-to-byte timeout


Display	Parameter	Action/Setting
SELEct	Select	Enter the Select menu (function, cutoff, out)
Function	Signal input conditioning	Select linear, square root, programmable exponent, or round horizontal tank function
Ch-A	Channel A	Select menu for channel A
Ch-V	Channel V	Select menu for channel V
LINEAR	Linear	Set meter for linear function and select number of linearization points
no PTS	Number of points	Set the number of linearization points (default: 2)
math	Math	Enter the setup menu for channel P math function
Multi	Multiplication	Channel P = ((A*V)+C)*F
Const	Constant	Constant used in channel P math
Adder	Adder	Addition constant used in channel P math calculation (C)

Display	Parameter	Action/Setting
Factor	Factor	Multiplication constant used in channel P math calculation (F)
Cutoff	Cutoff	Set low-flow cutoff
Ch-A	Channel A	Set low-flow cutoff for Channel A
Ch-V	Channel V	Set low-flow cutoff for Channel V
RoutePr	Analog output programming	Program analog output parameters
Route 1*	Analog output 1	Program analog output 1 (*1-3) parameters
Source	Source	Select source for the 4-20 mA output
brERH	Loop break	Set relay condition if loop break detected
OverRng	Overrange	Program mA output for display overrange
UndrRng	Underrange	Program mA output for display underrange
maxRH	Maximum	Program maximum mA output allowed
minRL	Minimum	Program minimum mA output allowed
CalRL	Calibrate	Calibrate 4-20 mA output (internal reference source used for scaling the output)
4 mA	4 mA output	Enter mA output value read by milliamp meter with at least 0.001 mA resolution
20 mA	20 mA output	Enter mA output value read by milliamp meter with at least 0.001 mA resolution
User	User I/O	Assign function keys and digital I/O
F1*	F1* function key	Assign F1 function key (*F1/F2/F3)
F4	F4 function	Assign F4 function (digital input)

Display	Parameter	Action/Setting
di 1	Digital input 1	Assign digital input 1 – 8, if expansion modules are connected
do 1	Digital output 1	Assign digital output 1 – 8, if expansion modules are connected
ICAL	Internal calibration	Enter internal calibration (used for recalibrating the meter with a calibrated signal source)
Ch-A	Channel A	Perform calibration on channel A
ICAL	Current calibration	Calibrate 4-20 mA current input (internal reference source used for scaling the input)
ILo	Current low	Calibrate low current input (e.g. 4 mA)
IHi	Current high	Calibrate high current input (e.g. 20 mA)
Error	Error	Error, calibration not successful, check signal or programmed value
Ch-V	Channel V	Perform calibration on channel V
VICAL	Voltage calibration	Calibrate voltage input
VLo	Voltage low	Calibrate low voltage input (e.g. 0 V)
VHi	Voltage high	Calibrate high voltage input (e.g. 10 V)
Error	Error	Error, calibration not successful, check signal or programmed value
diAG	Diagnostics	Display parameter settings
LED t	LED test	Test all LEDs
Info	Information	Display software and S/N information
Erase	Erase	Erase MeterView Pro software stored in meter's memory


Noise Filter (*F iLtEr*)

The noise filter is available for unusually noisy signals that cause an unstable process variable display. The noise filter averages the input signal over a certain period. The filter level determines the length of time over which the signal is averaged. The filter level can be set between 2 and 199. The higher the filter level, the longer the averaging time and so the longer it takes the display to settle to its final value. Setting the filter level to zero disables the filter function.



Noise Filter Bypass (*bYPASS*)

The noise filter bypass changes the behavior of the meter so that small variations in the signal are filtered out but large abrupt changes in the input signal are displayed immediately. The bypass value determines the minimum amount of signal change to be displayed immediately. All signal changes smaller than the bypass value are filtered or averaged by the meter. The noise filter bypass may be set between 0.1 and 99.9% of full scale.



Rounding Feature (*rOuNd*)

The rounding feature is used to give the user a steadier display with fluctuating signals. Rounding is used in addition to the filter function.

Rounding causes the display to round to the nearest value according to the rounding selected. This setting affects the last two digits, regardless of decimal point position.

Modbus RTU Serial Communications (SErIAL)

The meter is equipped with serial communications capability as a standard feature using Modbus RTU Serial Communication Protocol.

The meter may be connected to a PC for initial configuration via the onboard micro USB connection. For ongoing digital communications with a computer or other data terminal equipment, an RS-232, or RS-485 option is required; see *Ordering Information* on page 5 for details.




Warning!

Do not connect any equipment other than Precision Digital's expansion modules, cables, or meters to the RJ45 M-LINK connector. Otherwise damage will occur to the equipment and the meter.

Note: More detailed instructions are provided with each optional serial communications adapter.

Note: Changes made to the Serial menu are initialized after the menu key is pressed or after navigating

through the remainder of the serial parameters (i.e. pass the t-byte parameter).




When using more than one meter in a multi-drop mode, each meter must be provided with its own unique address. The meter address (Slave ID) may be programmed between 1 and 247. The transmit delay may be set between 0 and 199 ms. The parity can be set to even, odd, or none with 1 or 2 stop bits.

Changes made to the Serial menu are initialized after the MENU key is pressed or after navigating through the t-byte parameter.


Select Menu (SELEct)

The *Select* menu is used to select the number of linearization points applied to the input for either channel A or V, adder and factor constants applied to the power function $P = ((I \cdot V) + C) \cdot F$, low-flow cutoff, and analog output programming.



Multi-Point Linearization (L nEAR)

The multi-point linearization can be used to linearize the display for non-linear signals. The *Function* menu is used to access the *Linear* menu and select the number of linearization points applied to the input for either Ch-A or Ch-V. Meters are set up at the factory for linear function with 2-point linearization. Up to 32 linearization points can be selected for each channel under the linear function.



Note: After Scale is displayed continue pressing the Enter button until the meter completes the scaling of the input and display values.

Math Function (no ALEh)

Within the *Math* menu is the power function, $P = I \times V$, available on this meter to calculate the apparent power. This math function is a combination of input channels A and V, and will display when channel P is selected in the *Display* menu. The actual function, as calculated by the meter, is $P = ([A \times V] + C) \times F$, where C is the *adder* constant and F is the *Factor* constant.

Math Constants (ConSt)

The *Math Constants* menu is used to set the constants used in channel P math. The math function includes input channel A and V, as well as the adder constant C, and factor constant F.

The *Adder* constant (C) may be set from -99.999 to 999.999.

The *Factor* constant (F) may be set from 0.001 to 999.999.

Low-Flow Cutoff (CutoffF)

The low-flow cutoff feature allows the meter to be programmed so that any noise picked up from nearby transformers or other electric devices that cause an otherwise zero reading to fluctuate always displays zero on the meter.

The cutoff value may be programmed from 0 to 999999. The meter will display zero below the cutoff value. Programming the cutoff value to zero disables the cutoff feature.


Analog Output Programming (AnalogPr)

The *Analog Output Programming* menu is used to program the behavior of the 4-20 mA output. The following parameters and functions are programmed in this menu:

1. Source: Source for generating the 4-20 mA output
2. Overrange: Analog output value with display in overrange condition
3. Underrange: Analog output value with display in underrange condition
4. Break: Analog output value when loop break is detected
5. Max: Maximum analog output value allowed regardless of input
6. Min: Minimum analog output value allowed regardless of input
7. Calibrate: Calibrate the internal 4-20 mA source reference used to scale the 4-20 mA output

Analog Output Source

The analog output source can be based on either of the input channels (Ch-A, Ch-V), the power channel (Ch-P), maximum stored value of either input channel (Hi-A, Hi-V), minimum stored value of either input channel (Lo-A, Lo-V), relay set points, or the Modbus input.




Analog Output Calibration

To perform the analog output calibration, it is recommended to use a milliamp meter with a resolution of at least 0.1 μ A to measure the output current. The values saved internally during this procedure are used for scaling the 4-20 mA output in the *Setup* menu.

Programmable Function Keys User Menu (μ SEr)

The *User* menu allows the user to assign the front panel function keys F1, F2, and F3, the digital input F4 (a digital input located on the signal input connector), and up to eight additional digital inputs to access most of the menus or to activate certain functions immediately (e.g. reset max & min, hold relay states, etc.). This allows the meter to be greatly customized for use in specialized applications.

Up to eight digital outputs can be assigned to a number of actions and functions executed by the meter (i.e. alarms, relay acknowledgement, reset max, min, or max & min, tare, and reset tare). The digital outputs can be used to trigger external alarms or lights to indicate these specific events.



Function Keys & Digital I/O Available Settings

Refer to the following table for descriptions of each available function key or digital I/O setting.

Display	Description	Display	Description
↵	Reset the stored maximum display values for all channels	↵	Display maximum channel B display value on line 2
↵	Reset the stored minimum display values for all channels	↵	Display minimum Channel B display value on line 2
↵	Reset the stored maximum & minimum display values for all channels	↵	Display maximum & minimum channel B display values on line 2
RELAY	Directly access the relay menu	↵	Display maximum power channel P display value on line 2
SET *	Directly access the set point menu for relay 1 (*through 8)	↵	Display minimum power channel P display value on line 2
RELY d	Disable all relays until a button assigned to <i>enable relays</i> (RELY E) is pressed	↵	Display maximum & minimum power channel P display values on line 2
RELY E	Enable all relays to function as they have been programmed	F ON *	Force relay 1 (*through 4) into the on state. This function is used in conjunction with a digital input expansion module to achieve interlock functionality. See page 33 for details about interlock relays.
Hold	Hold current relay states as they are until a button assigned to <i>enable relays</i> (RELY E) is pressed	Control	Directly access the control menu
d Hold	Hold the current display value momentarily while the function key or digital input is active. The process value will continue to be calculated in the background.	d, SAbL	Disable the selected function key or digital I/O
d RUP	Scrolls values for A, V & P when activated. Keeps the last value for 10 seconds and then it returns to its assignment. Values are displayed on display line 1 and the corresponding channel and units on display line 2.	ACK	Acknowledge all active relays that are in a manual operation mode such as auto-manual or latching
↵	Display maximum channel A display value on line 1	RESET	Directly access the reset menu
↵	Display minimum channel A display value on line 1	MIMIC	Mimic the menu button functionality (digital inputs only)
↵	Display maximum & minimum channel A display values on line 1	RIGHT	Mimic the right arrow/F1 button functionality (digital inputs only)
		UP	Mimic the up arrow/F2 button functionality (digital inputs only)
		ENTER	Mimic the enter/F3 button functionality (digital inputs only)
		ALARM *	Provide indication when alarm 1 (*through 8) has been triggered (digital outputs only)

Internal Calibration (ICAL)

The meter is factory calibrated prior to shipment to read in amps and volts. The calibration equipment is certified to NIST standards.

The use of calibrated signal sources is necessary to perform the internal calibration of the meter. Check calibration of the meter at least every 12 months. Each input and input type must be recalibrated separately.

Notes:


1. If meter is in operation and it is intended to accept only one input type (e.g. 0-5 AAC or 0-300 VDC), recalibration of other input is not necessary.
2. Allow the meter to warm up for at least 15 minutes before performing the internal calibration procedure.

The *Internal calibration* menu is part of the *Advanced Features* menu.

1. Press and hold the Menu button for three seconds to access the advanced features of the meter.
2. Press the Up arrow button to scroll to the *Internal calibration* menu (ICAL) and press Enter.
3. Select channel A (CH-A) or channel V (CH-V) and press enter.
4. The meter displays either current calibration (C CAL) or voltage calibration (U CAL) depending on whether channel A (CH-A) or channel V (CH-V) is selected. Press Enter to start the calibration process.

Example of Internal Calibration for current input:

5. The meter displays *low* input current message (C Lo). Apply the low input signal and press Enter. The display flashes for a moment while the meter is accepting the low input signal.
6. After the display stops flashing, a number is displayed with the leftmost digit brighter than the rest. The bright digit is the active digit that can be changed by pressing the Up arrow button. Press the Right arrow button to move to the next digit.
7. Set the display value to correspond to the input signal being calibrated (e.g. 0 VDC).
8. The display moves to the *high* input calibration (C Hi). Apply the high input signal and press Enter.
9. Set the display for the high input calibration, in the same way as it was set for the low input calibration (e.g. 300 VDC).



The graphic above shows the calibration of the current input. The voltage input is calibrated in a similar way.

Tips:

- Low and high input signals can be any valid values within the range of the meter.
- Observe minimum input span requirements between input 1 and input 2.
- Low input should be less than high input signal.

Error Message (*Error*)

An error message indicates that the calibration or scaling process was not successful.

After the error message is displayed, the meter reverts to input 2 during calibration or scaling and to input 1 during internal calibration, allowing the appropriate input signal to be applied or programmed.

The error message might be caused by any of the following conditions:

1. Input signal is not connected to the proper terminals, or it is connected backwards.
2. Wrong signal selection in *Setup* menu.
3. Minimum input span requirements not maintained.

Minimum Input Span

The minimum input span is the minimum difference between input 1 and input 2 signals required to complete the calibration or scaling of the meter.

Input Range	Input 1 & Input 2 Span
+/- 0-5 ADC	+/- 0.005 ADC
0-5 AAC	0.010 AAC
+/- 0-300 VDC	+/- 0.1 VDC
0-300 VAC	0.3 VAC

Meter Operation

The meter is capable of accepting two input channels (A and V) of either current (0-5 AAC/DC) or voltage signals (0-300 VAC/DC) and displaying these signals in engineering units from -99999 to 999999 (e.g. a 1-5 A signal could be displayed as -50.000 to 50.000).

A power function channel (P) is available to perform the power operation ($P = IV$) on channel A and V, with adder and factor constants, and display the results. Engineering units or tags may be displayed with these three channels.

The dual-line display can be customized by the user. Typically, display line 1 is used to display the channel V, while line 2 is used to alternate between displaying input channels A and P.

Additionally, the meter can be set up to display any channel on line 1 and a unit or tag on line 2. The relays and analog output can be programmed to operate based on any channel.

Front Panel Buttons Operation

Button Symbol	Description
	Press to enter or exit Programming Mode, view settings, or exit max/min readings
	Press to reset max/min readings or other parameter/function assigned through the <i>User</i> menu
	Press to display max/min readings for channel A or other parameter/function assigned through the <i>User</i> menu
	Press to acknowledge relays or other parameters/function assigned through the <i>User</i> menu

Function Keys Operation

During operation, the programmable function keys operate according to the way they have been programmed in the *Advanced Features – User* menu.

The table above shows the factory default settings for F1, F2, and F3.

F4 Operation

A digital input, F4, is standard on the meter. This digital input is programmed identically to function keys F1, F2, and F3. The input is triggered with a contact closure to COM, or with an active low signal. During operation, F4 operates according to the way it has been programmed in the *Advanced Features – User* menu.

Maximum/Minimum Readings

The max & min readings (peak & valley) reached by the process can be displayed either continuously or momentary:

1. Display briefly by assigning to the F1-F3 function keys or to the digital inputs in the *User* menu.
2. Display continuously by assigning either display to max/min through the *Display* menu.

Any of the F1-F3 function keys (buttons) and the digital inputs can be programmed to reset the max & min readings. The meters are set at the factory to display the max reading by pressing the Up arrow/F2 button and to use the Right arrow/F1 button to access the *Reset* menu.

To display max and min channel A reading using function key with factory defaults:

1. Press Up arrow/F2 button to display minimum reading of channel A since the last reset/power-up. The display will then display the maximum reading of channel A since the last reset/power-up.
2. Press the Up arrow/F2 button again to display the minimum reading of channel A since the last reset/power up.
3. To reset max/min press Right arrow/F1 button to access the *Reset* menu. The max & min displays are reset to actual values.
4. Press Menu to exit max/min display reading.

Troubleshooting

Due to the many features and functions of the meter, it's possible that the setup of the meter does not agree with what an operator expects to see. If the meter is not working as expected, refer to the *Diagnostics* menu and consult the recommendations described below.

Diagnostics Menu (d ,RG)

The *Diagnostics* menu is located in the *Advanced Features* menu, to access *Diagnostics* menu see *Advanced Features Menu*, page 36.

This menu allows the user to test the functionality of all the meter LEDs, check the meter's software and version information, and erase the MeterView Pro software installation files from the meter. Press the Enter button to view the settings and the Menu button to exit at any time.

For a description of the diagnostic messages, see *Advanced Features Menu & Display Messages*, page 36.

Determining Software Version

To determine the software version of a meter:


1. Go to the *Diagnostics* menu (d ,RG) and press Enter button.
2. Press Up arrow button and scroll to Information menu (InFo).
3. Press Enter to access the software number (5Ft) and version (UEr) information. Write down the information as it is displayed. Continue pressing Enter until all the information is displayed.
4. The meter returns to Run Mode after displaying all the settings.

Reset Meter to Factory Defaults

When the parameters have been changed in a way that makes it difficult to determine what's happening, it might be better to start the setup process from the factory defaults.

Instructions to load factory defaults:

1. Enter the *Advanced Features* menu. See *Advanced Features Menu*, page 36.
2. Press Up arrow to go to *Diagnostics* menu
3. Press and hold Right arrow for three seconds, press Enter when display flashes rESEt.
Note: If Enter is not pressed within three seconds, the display returns to Run Mode.
4. The meter goes through an initialization sequence (similar as on power-up), and loads the factory default settings.



Factory Defaults & User Settings

The following table shows the factory setting for most of the programmable parameters on the meter.

Parameter	Display	Default Setting	Parameter	Display	Default Setting
Unit	Unit		Relay 1 assignment	Ch-U	Channel V
Unit, channel A	Ch-A	Amp	Relay 1 action	Rct 1	Automatic
Unit, channel V	Ch-U	Volt	Relay 1 set point	SEt 1	100.0
Unit, channel P	Ch-P	Power	Relay 1 reset point	rSEt 1	50.0
Number of points	no PtS		Relay 2 assignment	Ch-U	Channel V
Number of points, ch A	Ch-A	ddd.ddd	Relay 2 action	Rct 2	Automatic
Number of points, ch V	Ch-U	dddd.d	Relay 2 set point	SEt 2	200.0
Number of points, ch P	Ch-P	dddd.d	Relay 2 reset point	rSEt 2	150.0
Scaling, (channel A)	ScAL A		Relay 3 assignment	Ch-U	Channel V
Input 1, channel A	InP 1	0.000	Relay 3 action	Rct 3	Automatic
Display 1, channel A	d 1S 1	0.000	Relay 3 set point	SEt 3	300.0
Input 2, channel A	InP 2	5.000	Relay 3 reset point	rSEt 3	250.0
Display 2, channel A	d 1S 2	5.000	Relay 4 assignment	Ch-U	Channel V
Scaling (channel V)	ScAL U		Relay 4 action	Rct 4	Automatic
Input 1, channel V	InP 1	0.000	Relay 4 set point	SEt 4	400.0
Display 1, channel V	d 1S 1	0.0	Relay 4 reset point	rSEt 4	350.0
Input 2, channel V	InP 2	100.000	Fail-safe relay 1	FLS 1	Off
Display 2, channel V	d 1S 2	100.0	Fail-safe relay 2	FLS 2	Off
Math, channel P	rr ULt ,	Multiplication	Fail-safe relay 3	FLS 3	Off
Adder (constant C)	AddEr	0.000	Fail-safe relay 4	FLS 4	Off
Factor (constant F)	FActoR	1.000	On delay relay 1	On 1	0.0 sec
Filter	F ILtEr		Off delay relay 1	OFF 1	0.0 sec
Filter, channel A	Ch-A	70	On delay relay 2	On 2	0.0 sec
Filter, channel V	Ch-U	70	Off delay relay 2	OFF 2	0.0 sec
Bypass, channel A	bYPASS	0.2	On delay relay 3	On 3	0.0 sec
Bypass, channel V	bYPASS	0.2	Off delay relay 3	OFF 3	0.0 sec
Round	round	1	On delay relay 4	On 4	0.0 sec
Cutoff	CutOFF		Off delay relay 4	OFF 4	0.0 sec
Cutoff value, channel A	Ch-A	0.010	Loop break relay 1	LnorE	Ignore
Cutoff value, channel V	Ch-U	0.0 (disabled)	Loop break relay 2	LnorE	Ignore
Display assignment	dSPLY		Loop break relay 3	LnorE	Ignore
Line 1	d Ch-U	Channel V	Loop break relay 4	LnorE	Ignore
Line 2	d Ch-A	Channel A	Display 1 analog out	d 1S 1	4.000
Display intensity	d- IntY	8	Output 1 value	Out 1	4.000 mA
			Display 2 analog out	d 1S 2	20.000
			Output 2 value	Out 2	20.000 mA
			Source analog output	Source	Channel A
			Overrange output	OverAnG	21.000 mA

Parameter	Display	Default Setting
Underrange output	u-r RnG	3.000 mA
Loop break output	br ERH	3.000 mA
Maximum output	nr RH	23.000 mA
Minimum output	nr n	3.000 mA
Slave ID (Address)	SLAU id	247
Baud rate	bAud	9600
Transmit delay	tr dLY	50 ms
Parity	PRr tLY	Even
Byte-to-byte timeout	t-bYt	010 (0.1 sec)
F1 function key	F 1	Reset max & min
F2 function key	F 2	Line 1 Max & Min
F3 function key	F 3	Acknowledge relays
F4 function (digital input)	F 4	Acknowledge relays

Parameter	Display	Default Setting
Digital input 1	d i 1	Menu
Digital input 2	d i 2	Right arrow
Digital input 3	d i 3	Up arrow
Digital input 4	d i 4	Enter
Digital output 1	dO 1	Alarm 1
Digital output 2	dO 2	Alarm 2
Digital output 3	dO 3	Alarm 3
Digital output 4	dO 4	Alarm 4
Password 1	PR55 1	000000 (unlocked)
Password 2	PR55 2	000000 (unlocked)
Password 3	PR55 3	000000 (unlocked)

Troubleshooting Tips

Symptom	Check/Action
No display at all	Check power at power connector
Not able to change setup or programming, <i>L o c d</i> is displayed	Meter is password-protected, enter correct six-digit password to unlock
Meter displays error message during calibration (<i>E r r o r</i>)	Check: 1. Signal connections 2. Input selected in <i>Setup</i> menu 3. Minimum input span requirements
Meter displays 1. <i>999999</i> 2. <i>-99999</i>	Check: 1. Input selected in <i>Setup</i> menu 2. Corresponding signal at Signal connector
Display is unstable	Check: 1. Input signal stability and value 2. Display scaling vs. input signal 3. Filter and bypass values (increase)
Display response is too slow	Check filter and bypass values
Display reading is not accurate	Check: 1. Signal input conditioner selected: Linear, square root, etc. 2. Scaling or calibration
Display does not respond to input changes, reading a fixed number	Check: 1. Display assignment, it might be displaying max, min, or set point.
Display alternates between 1. <i>H i</i> and a number 2. <i>L o</i> and a number	Press Menu to exit max/min display readings.
Relay operation is reversed	Check: 1. Fail-safe in <i>Setup</i> menu 2. Wiring of relay contacts
Relay and status LED do not respond to signal	Check: 1. Relay action in <i>Setup</i> menu 2. Set and reset points
Flashing relay status LEDs	Relays in manual control mode or relay interlock switches opened.
Meter not communicating with application programs	Check: 1. Serial adapter and cable 2. Serial settings 3. Meter address and baud rate
If the display locks up or the meter does not respond at all	Cycle the power to reboot the microprocessor.
Other symptoms not described above	Call Technical Support for assistance.



EU Declaration of Conformity

Issued in accordance with ISO/IEC 17050-1:2004.

We,

Precision Digital Corporation

as the manufacturer, declare under our sole responsibility that the product(s),

Model PD6400 ProVu Series High Voltage & Current Meter

to which this declaration relates, is in conformity with the European Union Directives shown below:

2014/35/EU	Low Voltage Directive
2014/30/EU	EMC Directive
2011/65/EU	RoHS Directive

This conformity is based on compliance with the application of harmonized or applicable technical standards and, when applicable or required, a European Union notified body certification.

Standards:

EN 55022:2003
EN 61000-6-2:2001
EN 61010-1:2001
EN 61326:2006

The standards EN 55022:2003, EN 61000-6-2:2001, EN 61010-1:2001, and EN 61326:2006 are no longer harmonized. The requirements of these standards have been checked against the harmonized standards EN 55022:2010, EN 61000-6-2:2005, EN 61010-1:2010, and EN 61326:2013 and there were no major technical changes affecting the latest technical knowledge for the products listed above.

Product Markings:



Signed for and on behalf of Precision Digital Corporation:

Name: Jeffrey Peters
Company: Precision Digital Corporation
Title: President
Date: 04/20/2016

Document No: DoC PD6400 {042016}