

## Sample Consumption and Costs for Typical Appliances

Appliance	Wattage	Daily Cost	Monthly Cost	Annual Cost
Refrigerator	250 watts	\$.25	\$7.50	\$90
Computer	60 watts	\$.12	\$3.46	\$41
100 bulb on 12 hrs/day	100 watts	\$.10	\$2.88	\$35

Sample consumption and costs for typical appliances (using an electricity rate of 8 cents per kilowatt hour)

### Technical specifications

- > 120 VAC, 60 Hz, 15 amps continuous
- > \* Electronics handle 100-277v, 50/60 Hz, 20 amps. Universal version with country specific cord sets available for these applications
- > True power, RMS voltage, RMS current measured and displayed
- > Accuracy: +/- 1.5% + 3 counts, for example 100w load is +/- 1.8 watts  
*Below 60 watts, amps and power factor accuracy degrades, but wattage is accurate down to 0.5 watts*
- > USB interface (PRO and ES)
- > Ethernet interface (.Net)
- > Mains supply voltage fluctuations not to exceed +/- 10% of the nominal voltage
- > Input is via 6' electric cord, output is via outlet on top of meter

### For UL rating

- > Watts up? is intended for use on 20 amp circuits. Per NEC requirements, this is necessary when the load is above 12 amps.
- > Indoor use only
- > Altitude up to 2000 meters
- > Temperature 5° C to 40° C
- > Installation Category II
- > Pollution Degree 2
- > Maximum relative humidity 80% for temperatures up to 31° C decreasing linearly to 50% relative humidity at 40° C.

### Cleaning


Watts up? may be cleaned using a dry soft towel. Do not use liquids to clean. Do not disassemble. There are no spare parts. No preventative maintenance is required. If the case breaks or other physical damage is apparent, do not use.

### Warning

Watts up? is not a toy and is only intended for use by people over the age of 10. Never open the case. Shock hazard exists. Watts up? is not water resistant. As with all electronic equipment, avoid water and liquids. Do not touch Watts up? if it is wet. Watts up? is not repairable. If Watts up? is used in a manner not specified herein, the protection provided by Watts up? may be impaired.

### Warranty

Watts up? is guaranteed for 12 months from date of purchase. If a problem arises, simply return the meter to the place of purchase, along with proof of purchase, for a new meter or credit. For technical assistance or repair, please call toll free: 877.WATTSUP (877.928.8787). Electronic Educational Devices believes it is everyone's responsibility to help the environment. In this effort, e.e.d purposefully uses recycled components wherever possible and minimizes extraneous packaging. We hope that using Watts up? helps people understand the costs involved with electricity, and thereby encourages conservation and participation in environmental issues.



## OPERATORS MANUAL

POWER ANALYZER, WATT METER AND ELECTRICITY MONITOR

# watts up?

AND

wattsup? PRO



Printed on recycled paper, 20% post consumer content  
Illegal to reproduce without written permission  
© 2008 by E. E. D, incorporated.

**Electronic Educational Devices**  
3090 S Jamaica Ct, #306  
Aurora, CO 80014  
www.wattsupmeters.com



02/08 REV 9



## Operators Manual

Watts up? incorporates sophisticated digital electronics that enable precise and accurate measurements in an easy-to-use format. State-of-the-art digital microprocessor design utilizes high-frequency sampling of both voltage and current measurements for true power. Power factor is captured so even phase-shifted loads such as motors are accurately measured. Watts up?PRO downloads data to a PC for graphing and charting, and includes a payback calculator which automatically calculates the number of months to payback a new energy efficient appliance. The PRO ES has extra memory and the Watts up? .Net model is internet enabled and can switch the power to the load off. Fast, intuitive and easy-to-use, Watts up? quickly and accurately measures any appliance.

## Quick Reference Guide

This quick reference guide lists all the displays. They are numbered 1-19, and are each described in more detail in the pages that follow.

WATTS MODE		DISPLAY	
MODE default	SELECT default	1 CURRENT WATTS	Meter defaults to this mode on start
SELECT >click	1	2 MINIMUM WATTS	SELECT >hold H Resets Minimum Watts
SELECT >click	2	3 MAXIMUM WATTS	SELECT >hold H Resets Maximum Watts
SELECT >click	3	4 POWER FACTOR	
SELECT >click	4	5 VOLT AMPS (apparent PWR)	
WATT HOURS (KWH) MODE		6 CUMULATIVE WATT HOURS	
MODE >click	1	7 AVERAGE MONTHLY KWH	
SELECT default			
SELECT >click	1		
TIME MODE		8 ELAPSED TIME	SELECT >hold H Resets Time, Cost, KWH, Duty Cycle, Monthly Averages
MODE >click	2	9 DUTY CYCLE	SELECT >hold H Set Duty Cycle Threshold
SELECT default			
SELECT >click	1		
SELECT >click	2	10 FREQUENCY (Hz)	
COST MODE		11 CUMULATIVE COST	SELECT >hold H Set Rate
MODE >click	3	12 AVERAGE MONTHLY \$	SELECT >hold H Change \$ to ¢
SELECT default			
SELECT >click	1		
VOLTS MODE		13 LINE VOLTAGE	
MODE >click	4	14 MINIMUM VOLTS	SELECT >hold H Resets Minimum Volts
SELECT default			
SELECT >click	1		
SELECT >click	2	15 MAXIMUM VOLTS	SELECT >hold H Resets Maximum Volts
SELECT >click	3	16 LOAD SWITCHING	SELECT >hold H Switch Relay
.Net ONLY >			
AMPS MODE		16 CURRENT AMPS	Meter cycles back to WATTS after AMPS
MODE >click	5	17 MINIMUM AMPS	SELECT >hold H Resets Minimum Amps
SELECT default			
SELECT >click	1		
SELECT >click	2	18 MAXIMUM AMPS	SELECT >hold H Resets Maximum Amps

Thanks for purchasing Watts up? It will help you understand the cost of your electricity, your power quality and how your appliances operate. Watts up? is easy-to-use, but to make sure you get the most out of your meter, skim through the entire manual so you understand all the capabilities of Watts up?

## Getting started

PRO, PRO ES and .Net users should see that section at the end of the manual

1. Plug Watts up? into a standard properly grounded 120 volt AC wall outlet.
2. Plug an appliance into Watts up?
3. Turn on the appliance.

You'll see a reading like "35.7 WATTS." Watts up? always displays WATTS mode when first plugged in. There are six "modes" on the Watts up? meter. Modes are the major values that the meter displays. The modes are: WATTS, WATT HOURS, TIME, COST, VOLTS, and AMPS. Each mode includes one or more detail readings. For example, when in the WATT mode, you can see detail about watts, such as the MINIMUM WATTS or the MAXIMUM WATTS. The six modes and their detail readings are shown on the quick reference guide. To learn more about each mode, refer to the sections that follow.

4. To cycle through modes, simply click the MODE button. Each time you click the MODE button, you'll cycle to another mode.
5. To cycle through details within a mode, simply click the SELECT button while in that mode.
6. To reset any reading, press and hold the SELECT button for one second.

Clicking the MODE button cycles the display through all 6 modes, always in the same order. If you get confused, simply click the MODE button repeatedly until you get to the WATTS mode. Or simply unplug Watts up? and plug it back in. The display will now be in the WATTS mode. Unplugging Watts up? also resets all the values except RATE and THRESHOLD.

## MODES

This section describes each mode and the detail you can see within each mode. The detail readings are accessed by clicking the SELECT button while in the respective mode. If the MODE button is clicked while viewing a detail reading, Watts up? exits the detail reading and displays the next mode. For example, if MAXIMUM WATTS is being viewed and the MODE button is clicked, then the WATT HOUR mode is displayed. Examples shown represent a 150 watt bulb turned on eight hours per day for two days.

### WATTS MODE

Watts up? always turns on in WATTS mode.

150 WATTS

#### 1 CURRENT WATTS

When you turn on Watts up? or cycle to the WATTS mode, true RMS watts (the wattage currently being consumed) are automatically displayed. If nothing is plugged into Watts up?, the display reads zero (0).

MIN 8.8 WATTS

#### 2 MINIMUM WATTS

Click the SELECT button while in the WATTS mode. The display now shows the MINIMUM WATTS since Watts up? was plugged in or since the MINIMUM was last reset. This usually reads zero. It is used to determine the lowest wattage drawn for appliances that run continuously.

To reset the value after the appliance is on, press and hold the SELECT button for 1 second.

MAX 315 WATTS

#### 3 MAXIMUM WATTS

Click the SELECT button again. The display now shows the MAXIMUM WATTS since Watts up? was plugged in or since the MAXIMUM was last reset. This will read zero (or a small value, since there is often a surge when plugging Watts up? in) until an appliance is plugged in and turned on.


To reset the MAXIMUM, press and hold the SELECT button for one second.

#### 4 POWER FACTOR



Click the SELECT button again. The display now shows power factor for the appliance currently plugged in. POWER FACTOR is a number between zero and one, and it represents the phase angle shift between the voltage and current. To figure POWER FACTOR, Watts up? performs the following calculation: Watts / Volt \* Amps.

#### 5 VOLT AMPS (APPARENT PWR)




Click the SELECT button while in the WATT HOUR mode. The display now shows the volt amps, or apparent power. Volt amp is the product of the RMS Volts and RMS Amps. It does not take into account phase angle, which is the distinction between apparent power and active, or real power (see watts).

Click the SELECT button again. The display returns to the WATTS mode.


### WATT HOURS MODE

Click the MODE button.



#### 6 CUMULATIVE WATT HOURS

The display now indicates the cumulative WATT HOURS used since Watts up? was plugged in or TIME was last reset. Watt hours equal watts multiplied by time. For instance, a 150 watt bulb plugged in for 1 hour will consume 150 watt hours. In two hours, it will have consumed 300 watt hours. As the value increases, the display will automatically change units to KILOWATT HOURS (1 kilowatt hour (kwh) = 1000 watt hours).



#### 7 AVERAGE MONTHLY KWH

Click the SELECT button while in the WATT HOUR mode. The display now shows how many watt hours will be consumed each month. This is a pro-rated average, calculated since Watts up? was plugged in or TIME was last reset. The formula is:

$$\text{AVERAGE MONTHLY KWH} = (\text{watt hours}) / \{(\# \text{ of elapsed days}) / (30 \text{ days})\}.$$

It is used to determine how much electricity is used per month. Resetting the TIME will also reset the MONTHLY AVERAGE.

Click the SELECT button again. The display returns to the WATT HOURS mode.

### TIME MODE

Click the MODE button again.



#### 8 ELAPSED TIME

The display now indicates the elapsed TIME since Watts up? was plugged in or TIME was last reset. The TIME is first displayed in minutes and seconds (i.e. 1:25 means one minute and 25 seconds), up to 20 minutes. At 20 minutes, the display changes to hours and minutes and the HOURS symbol turns on (i.e. 1:25 now means one hour and 25 minutes). At 20 hours, the display changes to days and hours, and the DAYS symbol turns on (i.e. 12:17 means 12 days and 17 hours). At 20 days, the display changes to days with a decimal point, and the HOURS symbol turns off (i.e. 22.7 means 22 days and 7 tenths. 7 tenths is about 16 hours and 45 minutes).

0:00 – 19:59 (Zero to 19 minutes, 59 seconds)	Display > no symbol
0:20 – 19:59 (20 minutes to 19 hours, 59 minutes)	Display > HOURS
0:20 – 19:23 (20 hours to 19 days, 23 hours)	Display > HOURS and DAYS
20.1 – 1999 (20 1/10 days to 1999 days. After 1999 days, start over at 1 second)	Display > DAYS

Press and hold the SELECT button for one second while in the TIME mode to reset the TIME, WATT HOUR, COST, DUTY CYCLE and MONTHLY AVERAGE values back to zero. These values, as well as MINIMUMS and MAXIMUMS are also reset when Watts up? is unplugged.

#### 9 DUTY CYCLE



Click the SELECT button while in the TIME mode. The display now shows the DUTY CYCLE as a percentage (the number will be between zero and 100). DUTY CYCLE is the percent of time the appliance is above a threshold level. The default threshold is 100 watts, so the DUTY CYCLE will display the percentage of time the load is above 100 watts. The threshold can be changed to any number between one and 4800 watts.

For example, plug a refrigerator into Watts up?. The DUTY CYCLE will be the percent of time that the refrigerator compressor is running (if the threshold is set to more than the wattage of the refrigerator light bulb).

Click the SELECT button again. The display now returns to the TIME mode.



#### Duty Cycle Watts Threshold

DUTY CYCLE is the percent of time the appliance is above a threshold level. The default threshold is 100 watts, so the DUTY CYCLE will display the percent of time the appliance is above 100 watts. To change the threshold, go to the DUTY CYCLE display. Press and hold the SELECT button until the SET, DUTY CYCLE, WATTS symbols come on. UP/DOWN indicators will alternately flash. Click the SELECT button and the value will change in the direction of the arrow. Holding the SELECT button changes the value faster. Click the MODE button when the threshold is correct. It is recommended that you reset the TIME (see above) after changing the DUTY CYCLE THRESHOLD, because the duty cycle value is a real-time calculation.


#### 10 FREQUENCY (Hz)



Click the SELECT button while in the TIME mode. The display now shows the frequency. The meter measures the nominal frequency (50 Hz or 60 Hz) at initial power on. It then displays actual frequency in real time. Many calculations utilize calibration factors that are frequency dependent, so it is recommended that the meter be power cycled when changing between nominal frequencies.

### COST MODE

Click the MODE button again.



#### 11 CUMULATIVE COST

The display now indicates the amount of money consumed since Watts up? was plugged in or TIME was last reset. Tenths of a cent are initially displayed, so “.001” means 1/10 of a cent. “.234” means 23 and 4/10s cents. “3.24” means three dollars and 24 cents.



#### 12 AVERAGE MONTHLY COST

Click the SELECT button while in the COST mode. The display now shows the cost per month for whatever is plugged in. This is a pro-rated average, calculated since Watts up? was plugged in or TIME was last reset. The formula is:

$$\text{AVERAGE MONTHLY \$} = (\text{cost}) / \{(\# \text{ of elapsed days}) / (30 \text{ days})\}.$$

This value will change quickly when something is first plugged in. For refrigerators and other appliances that turn on and off, wait until the value no longer changes for an accurate reading. This may take a few hours, or even longer depending on how often the appliance cycles on and off.

Click the SELECT button again. The display now returns to the COST mode.

