

**Bulletin  
P-616KX-QS**



**Series 616KX Differential Pressure  
Transmitter**


---

**QUICK START GUIDE**


- 1. Mount** transmitter with pressure ports facing down using DIN clip feature or mounting screws. Do not overtighten mounting screws.
- 2. Attach wires** following diagram on reverse side. Turn off power before wiring.
- 3. Set Zero Calibration.** Apply zero pressure to both pressure ports on transmitter at the same time you press ZERO button for 3 seconds.
- 4. Scan** QR code with smart device to open the product web page for additional resources.



## Wiring Information



### 2-Wire 4 mA to 20 mA Output



### 3-Wire Voltage Output

See online User Guide for other wiring configuration.

**FR#: 444763-00**

© Copyright 2024 Dwyer Instruments, Inc.