

User Manual



BR260

High Definition Borescope Inspection Camera



Introduction

Congratulations on your purchase of the Triplet BR260 Borescope. The BR260 is a high performance industrial inspection camera with a 3-inch high definition color LCD. It is ergonomically designed so that the main functional buttons can be controlled with one hand. The snapshot and recording functions are supported, photos and videos can be saved on TF memory card (Micro-SD card). Features include an auxiliary light source and adjustable LED lights making it easy and handy to use in a dark environment.

Meter Description



Safety

This product is designed for industrial inspection camera.

- Avoid severe hits to the camera probe, and do not aggressively pull the cable.
- Please do not use it under high temperature, high magnetic environments or under strong light.
- Do not expose this product to extremely low or high temperatures
- If used for extended periods of time, please take out of the Alkaline battery from the device .
- Do not wipe the unit with corrosive chemical wash.

NOTICE:




WARNING ! This product is an industrial inspection camera and is not intended for medical use or human examination.

ACCESSORIES INSTALLATION



The installation of accessories is shown in the following figures

NOTE: Dual Lens Option Not Available for BR260 model at this time.

Single Lens



Dual Lens



Operation

BUTTON OPERATION



Power Button :

Press for 3 seconds to turn ON / OFF the screen.



Playback Button:

Playback : hold it to enter Photo or Video Playback, press again to exit.



Video Button :

Press it for Video recording .



Photo Button :

Press it to capture Photo images



OK /Screen rotation:

In setup menu, press the OK button to confirm.

In live view, press it to screen rotate 180°, press again to resume screen rotation 180°.



Camera LED Button :

Press it to adjust 3 levels brightness of the camera.

ENTER MENU SETTINGS

Date / time settings

Setting path:

MENU

Short press the button to enter setting page

Select first item(Date / time)on settings page

OK

Press button to select the Date / Time you need

Press up and down keys to change the Date /Time you need

MENU

Press to save your choice

Language settings

The default language is English, and the system supports English, Chinese, GermanFrench, Spanish, waian, Russian and Japanese.


Setting path:

MENU

Short press the button to enter setting page

Select second item (Language) on settings page


Press up and down keys to select the language you need

Press  to save your choice

TF card format settings

Setting path:

Short press the  button to enter setting page
Select the 3rd. item (format) on settings page

Press  keys to get into select format
Press up and down keys to select the Cancel or ok you need




Press  to save your choice


Photo taking / Video recording / Playback



Press  to switch to playback mode ,
Press up and down key to select photo or video to view,

and short press the  button to enter deleting photo or

video, press  to delete photo or video.

Press  to exit playback mode

TECHNICAL PARAMETERS:

Model	BR260
Screen	3.0inch color LCD display
Resolution	1280*720 ; 1920*1080

Horizontal viewing angle	60°
Language	Simplified Chinese, Traditional Chinese, English, French, German, Italy, Russian, Japanese, etc
Line length	2M 5M 7M
Focal length	3cm-10cm
Waterproof level	IP67(only for lens)
Lens diameter	5.5mm/8mm
Battery	Support 4pcs Alkaline battery
Battery life	About 3-4 hours

TROUBLESHOOTING:

Problem	Solution
The device can not be turned on	<ol style="list-style-type: none"> 1. Use after fully charging the battery. 2. Confirm whether the power supply has been successfully connected
TF card reading failed	<ol style="list-style-type: none"> 1. Confirm whether the TF card meets the requirements(the Highest supported format is 64GB Micro TF card in FAT 32,and the transmission speed must be Class 10 or higher) 2. Remove the TF card and reinsert it.

After the device is connected to The PC, can't read TF card	1. Reconnected the device and the PC 2. Confirm whether to enter mass storage mode
Smudges or smudges on the screen	1. Clean the screen carefully with a soft cloth

Warranty

Triplett / Jewell Instruments extends the following warranty to the original purchaser of these goods for use. Triplett warrants to the original purchaser for use that the products sold by it will be free from defects in workmanship and material for a period of (1) one year from the date of purchase. This warranty does not apply to any of our products which have been repaired or altered by unauthorized persons in any way or purchased from unauthorized distributors so as, in our sole judgment, to injure their stability or reliability, or which have been subject to misuse, abuse, misapplication, negligence, accident or which have had the serial numbers altered, defaced, or removed. Accessories, including batteries are not covered by this warranty

Copyright © 2022 Triplett