The PSU 206 is a `Eurocard' sized power supply unit designed primarily for OEM use. The linear regulator Ics used have over-current and over-temperature protection.

LASCAR PSU 206

Selecting Mains I/P Voltage

The unit is normally supplied connected for remove 240V link and insert BOTH 120V links



Triple Rail Power Supply




Simple Screw-Terminal Connection

- Encapsulated Mains Transformer
- ♠ Fixed 5V Output
- Separate, Fully Adjustable Split Rail Outputs

Derating Curve


The hotter the unit becomes the lower the current that may be taken from it. Enclosures should be adequately ventilated if necessary and power supplies should not be





Output	Terminals
5V Fixed	5V & 0z
Adjust, Pos	V+ & 0:
Adjust, Neg	V- & 0:

		Output	Terminals
•	120V 240	5V Fixed	5V & 0z
ŽĮ.	120	Adjust, Pos	V+ & 0:
	•	Adjust. Neg	V- & 0:




240 5 5	34.1186.0	25.00
	Adjust, Pos	V+ & 0
	Adjust, Neg	V- & 0

Safety
For safe operation the unit must be installed in an enclosure which prevents accidental contact. If the enclosure is made of a conducting material or the internal surfaces have a conductive coating, ensure that no part of the power supply will come into contact withit. The unit need not be earthed but to terminals [6] are provided as a convenient anchorage for earth leads. The mains lead to the unit must be fused with a 160mA (240V operation) or a 315mA (120V operation) fuse. Fuses should be IEC 127 part 2, sheet 3, DIN 41662 anti-surge spiral. In general, it is the responsibility of the user to ensure that the incorporation of the power supply unit into the OEM equipment conforms to the relevant sections of BS EN 61588-1: 1998, in accordance with the Low Voltage Directive (LVD9368/EEC).

If IN DOUBT CONTACT AN APPLICATIONS EXGINEER. DIMENSIONS All dimensions in mm (inches)

ed for 240V operation. For 120V operation



The PSU 206 is a 'Eurocard' sized power supply unit designed primarily for OEM use. The linear regulator Ics used have over-current and over-temperature protection

- Simple Screw-Terminal Connection
- Encapsulated Mains Transformer

Selecting Mains I/P Voltage


The unit is normally supplied connected for remove 240V link and insert BOTH 120V links

- Fixed 5V Output
- Separate, Fully Adjustable Split Rail Outputs



Derating Curve

The hotter the unit becomes the lower the current that may be taken from it. Enclosures should be adequately ventilated if necessary and power supplies should not be required to the control of the cont





Output	Terminals
5V Fixed	5V & 0:
Adjust, Pos	V+ & 0:
Adjust, Neg	V- & 0:

240V 120V 1200 240 1200 8 8 8 8	120
---------------------------------------	-----

or safe operation the unit must be installed in an enclosure which prevents accidental o	
nternal surfaces have a conductive coating, ensure that no part of the power supply w	
wo terminals (E) are provided as a convenient anchorage for earth leads. The mains le	
15mA (120V operation) fuse. Fuses should be IEC 127 part 2, sheet 3, DIN 41662 anti	
nsure that the incorporation of the power supply unit into the OEM equipment of	conforms to the relevant sections of BS EN 61558-1: 1998, in
ccordance with the Low Voltage Directive (LVD93/68/EEC).	
FINIT DOLUME CONTENCE AND A RIBUTO ATTIONIC PALCINITER	

ed for 240V operation. For 120V operation

