

HI151

Folding Pocket Thermometer

- CAL Check™
 - Alerts users of calibration status

The folding Checktemp®4 provides practical temperature measurement for the food service industry.

Special attention was given to the ergonomic form of Checktemp 4. This thermometer fits comfortably and securely in your hand while the LCD on the side of the handle remains easy to see and read. The fast-responding, fold-away probe is made of high quality stainless steel and can penetrate semi-frozen and semi-solid foods such as meats, ice cream and cheeses. When you are finished using your Checktemp 4, wipe the probe clean and fold it away. Checktemp 4 automatically turns off so you can safely carry it in your pocket.

CAL Check

As you unfold the stainless steel probe, the Checktemp 4 automatically turns on and immediately performs a calibration test. This unique Hanna feature, CAL Check, provides the security of knowing you have accurate measurements. CAL Check also lets you know if your battery level is low or if your meter requires recalibration.



Turns on and off by opening and closing the probe

| Specifications | HI151-00 (Checktemp 4C) | HI151-01 (Checktemp 4F) |
|----------------------|--|---|
| Range | -50.0 to 220°C | -58.0 to 428°F |
| Resolution | 0.1°C (-50.0 to 199.9°C); 1°C (200 to 220°C) | 0.1°F (-58.0 to 199.9°F); 1°F (200 to 428°F) |
| Accuracy | ±0.3°C ±1 digit (-20.0 to 90.0°C); ±1% F.S. ±1 digit (outside) | ±0.5°F ±1 digit (-4.0 to 194.0°F); ±1% F.S. ±1 digit (outside) |
| CAL Check | automatic, at start-up | |
| Probe | stainless steel probe with penetration tip; 117 x dia 3.5 mm (4.6 x dia 0.14") | |
| Battery Type / Life | 1.5V AA / approx. 25,000 hours of continuous use; auto-off after 8 minutes of non-use | |
| Environment | 0 to 50°C (32 to 122°F); RH max 95% | |
| Dimensions | 165 x 50 x 20 mm (6.5 x 2.0 x 0.8") | |
| Weight | 100 g (3.5 oz.) | |
| Ordering Information | HI151-00 (Checktemp 4 C) is supplied complete with battery and instructions HI151-01 (Checktemp 4 F) is supplied complete with battery and instructions | |

