

METRAPHASE 1

Phase Sequence Indicator

3-348-992-03
7/1.18

- **Displays phase sequence**
by means of 6 optically rotating LEDs with different colors
(clockwise: green, counterclockwise: red)
- **Displays nominal line voltage**
with 3 LEDs
- **Displays nominal line frequency**
with 6 LEDs
- **Phase search**
with 3 LEDs for L1, L2 and L3
- **Indication of errors for:**
 - Asymmetries
 - Missing phases

Useful accessories

- Protective rubber cover for rugged operation conditions



CAT IV

Applications

Phase sequence, line frequency and phase voltage are tested and displayed simultaneously after the METRAPHASE 1 test instrument has been connected to the system under test at all phases with the included, contact-protected connector cables. The instrument is suited for initial testing, as well as for testing after repairs and modifications.

Features

Convenient Testing with Only 2 Cables (2-pole measurement)

In addition to normal testing with 3 measurement cables, phase sequence can also be tested with only 2 cables. After connection to L1 has been established, phases L2 and L3 are scanned separately, one after the other. This operating mode is indicated by means of intelligent software which rules out the possibility of erroneous measurements.

Automatic Activation

The instrument is activated automatically as soon as a voltage of at least 100 V is applied to any 2 measurement sockets.

Battery Saving Circuit

The instrument is shut down automatically when zero voltage is applied in order to extend battery service life.

Applicable Regulations and Standards

IEC 61010-1/EN 61010-1/ VDE 0411-1	Safety requirements for electrical equipment for measurement, control and laboratory use
IEC 61557 Part 7/ EN 61557-7/ VDE 0413 Part 7	Phase sequence indicators
EN 60529 VDE 0470 Part 1	Test instruments and test procedures – Protection provided by enclosures (IP code)
DIN EN 61326-1 VDE 0843-20-1	Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 1: General requirements

Characteristic Values

Phase Direction	Phase Sequence	Phase Sequence LED Display	Phase Direction LED Display
Clockwise	L1 – L2 – L3	L1 L2 L3 light up	green LED rotates in clockwise direction
Counterclockwise	L3 – L2 – L1	L1 L2 L3 light up	red LED rotates in counterclockwise direction
Asymmetrical	Lx – N/PE – Lx	connection with N/PE not indicated	green or red LED rotates clockwise or counterclockwise depending upon connection
Phase Missing	Lx – X – Lx	missing phase does not light up, the other 2 do light up	—

METRAPHASE 1

Phase Sequence Indicator

Nominal 3 phase ~ line voltage indicated with one LED each for
120/208 V, 230/400 V, 400/690 V
Total line voltage range: 100 ... 690 V

Line frequency indicated with one LED each for
50 Hz, 60 Hz, 100 Hz, 200 Hz, 300 Hz, 400 Hz
Total frequency range: 15 ... 410 Hz

Input impedances

L1–L2 and L1–L3 approx. 500 kΩ
L2–L3 approx. 1 MΩ

Reference Conditions

Ambient
Temperature +23 °C ±2 K
Relative Humidity 40 ... 60 %
Battery Voltage 4.5 V ±0.25 V
Line Voltage 230/400 V ±0.5 %
Line Frequency 50 Hz ±0.1 Hz
Line Voltage
Waveshape sine, deviation between effective
and rectified values < 1 %

Ambient Conditions

Storage Temperature –25 °C ... +75 °C
Operating Temp. –10 °C ... +50 °C
Relative Humidity max. 75%, no condensation
Elevation to 2000 m

Power Supply

Batteries 4 cells, alkaline-manganese
per IEC LR6 (4 x AA-size)
Battery Voltage 4 V ... 6 V
Battery Service Life with alkaline-manganese cells:
approx. 100 hrs.

Electrical Safety

Protection Class II per IEC 61010-1
Measuring Category IV
Operating Voltage 600 V
Contamination Level 2
Test Voltage 5.55 kV

Mechanical Design

Protection IP40 per DIN VDE 0470 Part 1/EN 60529 Extract from table on the meaning of IP codes

IP XY (1 st digit X)	Protection against foreign object entry	IP XY (2 nd digit Y)	Protection against the penetration of water
4	≥ 1.0 mm dia.	0	not protected

Dimensions 84 mm x 195 mm x 35 mm
Weight approx. 0.3 kg with batteries

Standard Equipment

- 1 phase sequence indicator
- 3 plug-on measurement cables with contact-protected plugs
600 V CAT IV 10 A
- 3 test probes for attachment to contact-protected plugs
1000 V CAT IV 1 A / 1000 V CAT II 32 A
- 1 alligator clip for attachment to contact-protected plugs
600 V CAT IV 19 A
- 4 batteries
- 1 operating instructions
- 1 carrying case

Order Information

Description	Type	Article Number
Phase sequence indicator in HC20 carrying case	METRAPHASE 1	M620A
Accessories		
Variable plug adapter set 3.5 .. 12 mm	Z500A	Z500A
Protective rubber cover with prop-up flap and carrying strap	GH18	GTZ3212000R0001

See *Measuring Instruments and Testers Catalog*
for additional information concerning accessories.

Edited in Germany • Subject to change without notice • A pdf version is available on the internet